



I/A SERIES®  
HEADBOX CONTROL  
MAINTENANCE GUIDE



A Siebe Group Company

Foxboro, Fox and I/A Series are registered trademarks of The Foxboro Company.  
The Intelligent Automation People is a service mark of The Foxboro Company.  
Siebe is a registered trademark of Siebe, plc.

Copyright 1999 by The Foxboro Company  
All rights reserved

## SOFTWARE LICENSE AND COPYRIGHT INFORMATION

Before using the Foxboro supplied software supported by this Foxboro documentation, you should read and understand the following information concerning copyrighted software.

1. The license provisions in the Foxboro Software License for your system govern your obligations and usage rights to the software described in this documentation. If any portion of those license provisions is violated, The Foxboro Company will no longer provide you with support services and assumes no further responsibilities for your system or its operation.
2. All software issued by The Foxboro Company, and copies of the software that you are specifically permitted to make, are protected in accordance with Federal copyright laws. It is illegal to make any copies of any software media provided to you by The Foxboro Company for any purpose other than those permitted in the Foxboro Software License.

# *Contents*

## *Headbox Control Maintenance Guide*

- Overview ..... 1**
- Software Architecture ..... 3**
- Jet/Wire Calculation ..... 5
- Dryline Calculation ..... 5
- Headbox Level ..... 8
- Settings ..... 9**
- Historian Variables ..... 12**
- Troubleshooting Guide ..... 13**
- Appendix: Rush-Drag Conversion ..... 16**

# *Preface*

The Foxboro Headbox Control package improves the performance of your paper machine. It regulates headbox functions to assure a uniformly high quality of paper at the reel.

## *Audience*

People who monitor and operate paper machines under The Foxboro Company I/A Series distributed control system should be familiar with the contents of this guide.

## *Related Document*

*Headbox Control Operator Guide (ISD0014TE)*

## *System Requirements*


The hardware and software requirements for the Headbox Control package are:

- 5% of a CP-40 for supervisory control
- Minimum AW51-B workstation, with a minimum of 96 MB of memory, 2.1 GB hard drive and Historian 1000
- I/A Series software, Release 4.3 or later
- WP51 display stations


# Overview

The Headbox Control package assures a well-regulated flow through the headbox (Figure 1). The *Headbox Control Maintenance Guide* outlines control strategies and tuning procedures for the package. It assumes familiarity with the Foxboro I/A Series distributed control system. Within this operating environment, the maintenance guide discusses these topics:


- Data flow for the headbox control loops
- Calculation of the total head setpoint
- Calculation of the slice position setpoint
- Regulation of the pond level
- Gain settings for dryline control
- Historian variables
- Basic troubleshooting procedures




**Figure 1** Hydraulic Headbox


**Note**  The Headbox Control package is based on Jet/Wire calculations, but the headbox compound contains the blocks needed to calculate Rush-Drag. To convert the Headbox Control package to Rush-Drag, see the Appendix: Rush-Drag Conversion on page 16.

The application includes a headbox control simulator to train machine operators and to check out the Headbox Control package. The simulator uses the MD Control Summary display (Figure 2) documented in the *Headbox Control Operator Guide* (ISD0014TE). Because the application has only one set of output blocks, you cannot run the simulation and the application simultaneously. Therefore, use the simulator during factory testing and operator training, before you connect the blocks to the process. After you connect the blocks to the process, the controls on the operator display are all operational.

**Note**  The names of supervisory loops in the MD Control Summary display use gray lettering, and the names of regulatory loops use white lettering. The names of the regulatory control loops at your site may not be the same as those shown in Figure 2.



**Figure 2** Machine-Direction Control Summary Display

**Note**  Block and parameter names in this guide assume a Headbox Control package installed on Paper Machine 1. The headbox control compound on the first machine is named P1\_HEADBOX. P4\_HEADBOX indicates a Headbox Control package running on Paper Machine 4.

# *Software Architecture*

The Headbox Control package regulates total head, the vertical slice opening, and several other variables connected with the operation of the headbox. The entire control package resides in the control processor, in the compound P1\_HEADBOX. Figure 3 on page 6 and Figure 4 on page 7 illustrate the software architecture and control strategies used in the package. They diagram the flow of data among the various blocks in P1\_HEADBOX. Several features of the package are worth noting:

- The jet/wire setpoint determines the relationship between jet velocity and wire speed. If the ratio is greater than 1, the velocity of the stock as it leaves the headbox (jet velocity) is greater than the speed of the wire. If the ratio is less than 1, the velocity of the stock as it leaves the headbox is less than the speed of the wire.
- The jet/wire calculation regulates total head to assure that the ratio of jet velocity to wire speed is constant.
- The package sends a total head setpoint to the total head controller. The total head controller typically regulates the output to the fan pump to achieve the setpoint.
- The dryline calculation regulates the slice position to maintain the position of the dryline.
- The package sends a slice position setpoint to the slice position controller. The slice position controller opens and closes the slice to achieve the setpoint.


The Headbox Control package contains five control loops:

- Jet/Wire Ratio
- Total Head
- Dryline
- Slice
- Headbox Level

Table 1 contains descriptive information for each of these control loops. The name of the loop appears in the first column of the table. The Loop Type is either supervisory or regulatory (see the *Headbox Control Operator Guide* for a comparison of these two loop types). The Compound:Block Name gives the name of the loop in the I/A Series control database. Typical Units of Measurement refers to the values in the Measurement, Setpoint, and Output columns of the Machine-Direction Control Summary display (Figure 2 on page 2).

**Table 1 Control Loop Descriptions**

Loop Name	Loop Type	Compound:Block Name	Typical Units of Measurement	
			Meas/Spt	Output
Jet/Wire Ratio	Supervisory	P1_HEADBOX:JETWIRECALC	N/A	N/A
Total Head	Regulatory	P1_HEADBOX:TOTALHEAD	Pressure in inches of water	% output (fan pump)
Dryline	Supervisory	P1_HEADBOX:DRYLINECALC	N/A	N/A
Slice	Regulatory	P1_HEADBOX:SLICEVERT	Inches	N/A
Headbox Level	Regulatory	P1_HEADBOX:PONDLEVEL	% level (headbox)	% output (air pad/vent valve)

**Note**  Regulatory control configurations vary substantially from site to site. The regulatory control loops at your plant may have block names that differ from those listed in Table 1, and these blocks may reside in different compounds. In some setups one or more regulatory loops may be absent altogether. Regulatory controls are included for reference and completeness, and to ensure the simulator operates properly.



# Jet/Wire Calculation

The jet/wire calculation uses two equations. The first one relates the target jet velocity,  $V$ , to the operator-entered jet/wire ratio setpoint and to the wire speed:

$$V = (\text{Ratio Setpoint}) (\text{Wire Speed})$$

If the ratio setpoint is 1.1, for example, the target jet velocity is 10% higher than the wire speed.

The second equation relates the target jet velocity,  $V$ , to the target total head,  $h$ :

$$V = \sqrt{2g_c h}$$

where  $g_c$  is the gravity constant. If you solve this equation for total head, you have:

$$V^2 = 2g_c h$$


And:

$$h = \frac{V^2}{2g_c}$$


The block P1\_HEADBOX:JETWIRECALC calculates both the target jet velocity and the target total head. Figure 3 on page 6 illustrates the flow of data related to this block.

# Dryline Calculation

The dryline position varies according to the volume of water that passes through the vertical slice opening. When Dryline is in Automatic and the stock gain or speed gain setting is not zero, Dryline updates the setpoint of the slice position controller. Then the vertical slice opening adjusts to changes in the thick stock flow rate or to changes in the wire speed. As the thick stock flow rate decreases or the wire speed increases, the slice closes to prevent the dryline from moving forward. Figure 4 on page 7 illustrates the flow of data related to the dryline calculation. For an explanation of the equation used in this calculation, see *Gain Settings* on page 11.




**Figure 3 Jet/Wire Calculation**



**Figure 4 Dryline Calculation**

# Headbox Level

Headbox Level is a regulatory control loop. It maintains an air pad in the headbox that regulates the pond level (Figure 5). An air compressor and a dual-valve system at the top of the headbox maintain the air pressure on the surface of the water. To increase the air pad pressure, the compressed air valve opens and the vent valve closes. To reduce the air pad pressure, the compressed air valve closes and the vent valve opens. As flow through the headbox fluctuates, the air pad serves as a cushion that helps to control the headbox level.



**Figure 5** *Headbox Level*

**Note** *Headbox Level is a regulatory controller that may not be required for your system. Please see the note on page 4.*



# Settings

This section contains general definitions and procedures related to the MD Headbox Tuning Parameter table (Figure 6). It explains how to change a setting, and describes the gain settings used to tune the Dryline control loop. The table arranges information for these settings in five columns:

- *Description* – The name of the parameter.
- *Block and Parameter* – The parameter designation in the I/A Series control database.
- *Units* – The units of measurement for the parameter.
- *Nominal Value* – Factory settings intended for use as a reference during maintenance procedures.
- *Actual Value* – The actual value of the parameter as set by a process control engineer.

FOXBORO: Display Manager PPAW07:PPAW07 11:33 6-22-99

Sys Alarm Cdcntl Scannr Mdcntl Profil Prodn GrdChg Trends

PM1 - MD HEADBOX TUNING PARAMETER TABLE

DESCRIPTION	BLOCK AND PARAMETER	UNITS	NOM. VAL.	ACT. VAL.
DRYLINE STOCK GAIN	DRYLINECALC.RI0008	IN/GPM	0.0001	0.000000
DRYLINE SPEED GAIN	DRYLINECALC.RI0009	IN/FPM	-0.0001	-0.000050
TOTAL HEAD SETPOINT RATE OF CHANGE LIMIT	JETWIRELIM.ROCLIM	INH20/SEC	0.1000	0.100000
VERTICLE SLICE SETPOINT RATE OF CHANGE LIMIT	DRYLINELIM.ROCLIM	IN/SEC	0.0100	0.010000

PREV DISP PRINT SCREEN

Figure 6 Headbox Tuning Parameter Table


**Note**  *The numbers in the Nominal Value column are factory settings or reference values. Use them if necessary as a starting point during machine maintenance or software maintenance. The numbers in the Actual Value column are for illustration only. Determine the actual values for your machine independently.*


Figure 6 on page 9 contains four settings for the Headbox Control package:

- Dryline stock gain
- Dryline speed gain
- Total head setpoint rate of change limit
- Vertical slice setpoint rate of change limit

## *How to Change a Setting*

Figure 6 on page 9 contains the tuning parameters relevant to the Headbox Control package. To change the value of a tuning parameter:

1. Move the cursor to the setting in the Actual Value column that you want to change. A small rectangle appears around the setting.
2. Click the setting. A blue data entry field appears.
3. Type the new setting and press Enter.

**Note**  *After a successful tuning operation, perform an Upload and Checkpoint to ensure the tuning parameters are saved permanently. As a precaution, do a SaveAll as well.*

## *Gain Settings*

The gain settings for dryline control should reflect the operating characteristics of your machine. The discussion below uses examples based on the settings in the Actual Value column of Figure 6 on page 9. The operating characteristics and particular settings for your machine will differ.

The Dryline control loop uses the following equation to calculate a new slice position:

$$\begin{aligned} & (\text{Change in Thick Stock Flow}) (\text{Thick Stock Flow Gain}) + \\ & (\text{Change in Machine Speed}) (\text{Speed Gain}) + \\ & \text{Current Slice Position} = \text{New Slice Position} \end{aligned}$$

For example, let the thick stock flow rate change from 2,000 gpm to 2,020 gpm. The change in the thick stock flow rate is 20 gallons per minute. Let the stock flow gain equal 0.0000. (As a result, the term drops out of the dryline calculation.) If the machine speed increases from 1,700 fpm to 1,750 fpm, the change in machine speed is 50 feet per minute. Let the speed gain equal -0.0005. Lastly, let the current height of the slice equal 1.5 inches. These figures yield the following calculation:

$$\begin{aligned} & (2,000 \text{ gpm}) (0.0000 \text{ in./gpm}) + \\ & (50 \text{ fpm}) (-0.0005 \text{ in./fpm}) + 1.5 \text{ in.} = \\ & 0.00 + (-0.025 \text{ in.}) + 1.5 \text{ in.} = 1.475 \text{ inches} \end{aligned}$$

The new vertical slice opening is 1.475 inches, or 0.025 inches less than before. If the machine speed increases, total head increases to maintain a constant jet/wire ratio. As a result, more water flows onto the wire, and the dryline begins to move forward. To restrict the flow, Dryline control lowers the slice. If in this example the machine speed *decreases* 50 fpm, the vertical slice opens 0.025 inches.

## *Rate of Change Limits*


The rate of change limits in the Tuning Parameter table keep the total head and vertical slice setpoints from changing too rapidly. The total head rate of change limit in Figure 6 on page 9 is 0.1 inches of water per second. The vertical slice setpoint rate of change limit is 0.01 inches per second. Set these limits low enough that when a speed change or a grade change occurs, the setpoints do not change so rapidly as to upset the process.

# Historian Variables

To record and analyze the performance of the Headbox Control package, store historical data on any of several variables using the I/A Series Historian. Table 2 contains a list of the variables available for the Historian.

**Table 2** *Historian Variables*

Variable Description	Variable Name
Headbox consistency measurement	P1_HEADBOX:DRYLINEMEAS.MEAS
Headbox consistency output	P1_HEADBOX:DRYLINEMEAS.SPT
Headbox jet/wire measurement	P1_HEADBOX:JETWIREMEAS.MEAS
Headbox jet/wire setpoint	P1_HEADBOX:JETWIREMEAS.SPT
Pond level measurement	P1_HEADBOX:PONDLEVEL.MEAS
Pond level output	P1_HEADBOX:PONDLEVEL.OUT
Pond level setpoint	P1_HEADBOX:PONDLEVEL.SPT
Headbox rush-drag measurement	P1_HEADBOX:RUSHDRAGMEAS.MEAS
Headbox rush-drag setpoint	P1_HEADBOX:RUSHDRAGMEAS.SPT
Vertical slice position measurement	P1_HEADBOX:SLICEVERT.MEAS
Vertical slice position setpoint	P1_HEADBOX:SLICEVERT.SPT
Total head measurement	P1_HEADBOX:TOTALHEAD.MEAS
Total head output	P1_HEADBOX:TOTALHEAD.OUT
Total head bias	P1_HEADBOX:TOTALHEAD.BIAS
Total head setpoint	P1_HEADBOX:TOTALHEAD.SPT

**Note**  As indicated in the note on page 4, the block names for *TOTALHEAD*, *SLICEVERT*, AND *PONDLEVEL* may be different at your site. To take the configuration of regulatory controls at your site into account, adjust the variable names in Table 2 as necessary.

When you configure the Historian, set the parameters for recording and storing data as follows:

- The deadband should be 0.1% for inputs and setpoints, 0.5% for outputs.
- The recommended scan rate is 10 seconds.
- The recommended retention time is 72 hours.



# Troubleshooting Guide

When both Jet/Wire Ratio and Dryline are in Automatic and the control system has no fault conditions, the status indicators in the Headbox Control Help overlay are all green (see the right side of Figure 7). To bring up the Help overlay, click Headbox Control **Help** in either the MD Control Summary display (Figure 2 on page 2) or the Headbox Detail display (see the left side of Figure 7).




Figure 7 Headbox Control Help Overlay

Specific fault conditions in the control system cause a status indicator on the Help overlay to become gray. See the *Headbox Control Operator Guide* (ISD0014TE) for a description of these fault conditions. Table 3 contains a list of parameters and data points to check in connection with each of the status indicators.

**Table 3 Troubleshooting Checks**

Status Indicators	Description of Problem	Parameters to Check
Op Request Headbox Jet/Wire	Jet/ Wire Ratio does not go into Automatic when requested.	P1_HEADBOX:JETWIRECALC.BI01 P1_HEADBOX:JETWIRESTAT.PAKCRB
Total Head in Cascade	Total Head is not in Cascade when it ought to be.	P1_HEADBOX:TOTALHEAD.LR
Op Request Dryline	Dryline does not go into Automatic when requested.	P1_HEADBOX:DRYLINECALC.BI0001 P1_HEADBOX:DRYLINESTAT.PAKCRB
Slice in Cascade	Slice is not in Cascade when it ought to be.	P1_HEADBOX:SLICEVERT.LR


*Note*  As you locate the parameters listed in Table 3, recall that the block names for regulatory loops may differ at your site. See the note on page 4.

Table 4 shows how P1\_HEADBOX:JETWIRESTAT.PAKCRB and P1\_HEADBOX:DRYLINESTAT.PAKCRB combine inputs from the operator display and from JETWIRECALC or DRYLINECALC to determine the control status of the supervisory loops, Jet/Wire Ratio and Dryline.

**Table 4 PAKCRB Logic for Jet/Wire Ratio and Dryline**

Auto/Manual Request from Operator	Status Bit from JETWIRECALC or DRYLINECALC	Control Status of Jet/Wire Ratio or Dryline	Description
0 = Manual	0 = Good	Off	Operator requests manual. Equipment and data status immaterial.
0 = Manual	1 = Bad	Off	Operator requests manual. Equipment and data status immaterial.
1 = Automatic	0 = Good	Auto	Operator requests Automatic. Equipment and data status good.
1 = Automatic	1 = Bad	Susp	Operator requests Automatic. Equipment or data status bad.

Table 5 shows how to interpret the Boolean status parameters in P1\_HEADBOX.

**Table 5** *Headbox Status Indicators*

Status Indicator	Key Parameter	Interpretation of Boolean Variable
Total Head in Cascade	P1_HEADBOX:TOTALHEAD.INITO	True = Bad (Total Head not in Cascade)
Slice in Cascade	P1_HEADBOX:SLICEVERT.INITO	True = Bad (Slice not in Cascade)

### *Total Head in Cascade*

The output parameter for this indicator, P1\_HEADBOX:TOTALHEAD.LR, is the Local/Remote switch of the fan pump controller. When the fan pump controller is under local control, it cannot be in Cascade. The actual Compound:Block.Parameter designation of P1\_HEADBOX:TOTALHEAD.LR depends on the names and configuration of regulatory controllers at your site.

### *Jet/Wire Ratio (Operator Request)*

Op Request Headbox Jet/Wire shows whether the operator has put Jet/Wire Ratio in Automatic from the MD Control Summary display. If the operator has requested Automatic and the control loop remains suspended, the status bit from JETWIRECALC must be bad (see row four in Table 4). Table 4 shows how P1\_HEADBOX:JETWIRESTAT.PAKCRB combines two Boolean output bits into the three possible control statuses: Automatic, Off, and Suspend. Check the output bits listed in row one of Table 3 when Jet/Wire Ratio should be in Automatic but is not.

### *Slice in Cascade*

The output parameter for this indicator, P1\_HEADBOX:SLICEVERT.LR, is the Local/Remote switch of the slice controller. When the slice controller is under local control, it cannot be in Cascade. The actual Compound:Block.Parameter designation of P1\_HEADBOX:SLICEVERT.LR depends on the names and configuration of regulatory controllers at your site.

### *Dryline (Operator Request)*

Op Request Dryline shows whether the operator has put Dryline in Automatic from the MD Control Summary display. If the operator has requested Automatic and the control loop remains suspended, the status bit from DRYLINECALC must be bad (see row four in Table 4). Table 4 shows how P1\_HEADBOX:DRYLINESTAT.PAKCRB combines two Boolean output bits into the three possible control statuses: Automatic, Off, and Suspend. Check the output bits listed in row three of Table 3 when Dryline should be in Automatic but is not.

# *Appendix: Rush-Drag Conversion*

To convert the Headbox Control package from Jet/Wire to Rush-Drag, execute the following steps:

1. Make a backup copy of all the displays in the package.
2. Change directory to **/opt/pm1/mdcntl**.
3. Type **d\_edit -c,JETWIRE,RUSHDRAG, MD\_SUM HD\_BOX** (Enter this command twice).
4. Type **d\_edit -T,Jet/Wire Ratio,Rush Drag, MD\_SUM HD\_BOX**.
5. Change directory to **/opt/pm1/ovl**.
6. Type **d\_edit -c,JETWIRE,RUSHDRAG, hdbxhelp**.
7. Type **d\_edit -T,Jet/Wire Ratio,Rush Drag, hdbxhelp**.
8. In the Integrated Control Configurator, disconnect P1\_HEADBOX:TOTALHEAD.RSP from JETWIRELIM and connect it to RUSHDRAGLIM.





# The Intelligent Automation People



## **The Foxboro Company**

Foxboro, MA 02035-2099

Telephone (508) 543-8750

(888) 369-2676

Facsimile (508) 549-6750

Headquarters, North America, 1-800-521-0451

Latin America, +508-543-8750

Europe, +49-711-502-0

Mideast (Saudi Arabia), 966-3-859-1111, Ext. 1501

Mideast (Dubai), 971-4-319-050

Far East, +65-265-7155

© The Foxboro Company 1999

All rights reserved.

PUB ISD0015TE

Printed in U.S.A.