

Australia:

Rinstrum Pty Ltd
Ph: + 61 7 3216 7166
axleweighr.au@rinstrum.com

USA:

Rinstrum Inc.
Toll Free 1 877 829 9152
Ph: +1 248 680 0320
axleweighr.us@rinstrum.com

Europe:

Rinstrum Europe GmbH
Ph: 49(0)6162 91 65 6-0
axleweighr.eu@rinstrum.com

Local Dealer:




www.axleWEIGHr.com



Drive over the scale at a constant speed ~3MPH | ~5km/h

The scale will automatically weigh each axle and calculate the total.



In-motion Axle Scale

PATENT PENDING

axleWEIGH^h

rinstrum smart weighing[®]



- ✓ Monitor yields, loads, waste and compliance
- ✓ Document truck weights and eliminate overload fines.
- ✓ Determine and maximise your load and axle weights before you go over a weighbridge.
- ✓ Relocatable design for rented or variable work sites.



Easy

Just install, add power, zero the scale and start weighing. The axleWEIGHh is preconfigured for easy installation. The load cells are factory calibrated and the indicator is preprogrammed. All wiring is DIY terminating with screw on watertight M12 connectors.



Accurate

On average better than $\pm 0.5\%$ repeatability can be expected. Company testing as well as numerous field installs have shown that with extended flat and level concrete approaches better accuracy can be achieved. Individual results may vary. Well maintained vehicles weigh the best. Never worry about being overloaded again.



Economical

About 1/3 of the cost of a full length truck scale. With the axleWEIGHh you will always know the total vehicle weight and the individual axle weights. Installation generally takes half a day and no costly foundation work. No limit on the number of axles, allows for any truck configuration or length. Can even be installed in a gravel driveway removing the need for costly approaches and exits.



Innovative & Trusted

Rinstrum's patented design produces fast accurate weights without stopping on the scale or interrupting the flow of traffic using weighing technology that we have been fine tuning over the past 20 years. Farm and jobsite management software creates a CSV file for every transaction with "farm and field" or "material and job number".

Single Pass Weighing With Known Tare Weight

ID: 111ABC
Tare: 25,000lb

AXLE 1 :	9788
AXLE 2 :	9999
AXLE 3 :	9999
AXLE 4 :	9999
AXLE 5 :	9960

10/02/10 09:50:00
TRUCK: 111ABC
SEQ: 000000176

AXLES:	5
GROSS:	49700lb
TARE:	25000lb FT
NET:	24720lb

- ▶ Press the TRUCK Key
 - ▶ Enter your known Tare weight then OK
 - ▶ Drive over the scale
- OR
- ▶ Press the TRUCK Key
 - ▶ Enter Truck ID to recall a stored Tare weight then OK
 - ▶ Drive over the scale

Two Pass Weighing - Weigh In and Weigh Out

IN

30032lb

AXLE 1 :	6000
AXLE 2 :	5800
AXLE 3 :	6000
AXLE 4 :	5900
AXLE 5 :	6332

10/02/10 09:38:45
TRUCK: 12
SEQ: 000000173

AXLES: 5
WEIGH IN: 30032lb

OUT

60115lb

AXLE 1 :	11200
AXLE 2 :	12300
AXLE 3 :	13100
AXLE 4 :	12900
AXLE 5 :	13615

10/02/10 09:38:45
TRUCK: 12
SEQ: 000000173

WEIGH IN: 30032lb
WEIGH OUT: 60115lb
NET: 30083lb

- INBOUND**
- ▶ Press the TRUCK Key then OK
 - ▶ Drive over the scale
- OUTBOUND**
- ▶ Use Up/Down arrows to select your Truck ID then OK
 - ▶ Drive over the scale