



30-20905A

**10,000 LB CAPACITY
2-POST LIFT**



INSTALLATION AND SERVICE MANUAL

CONTENTS

Product Features and Specifications	1
Installation Requirement	3
Steps of Installation	4
Exploded View	10
Test Run	12
Operation Instruction	13
Maintenance	14
Trouble Shooting	15
Parts List	16

PRODUCT FEATURES AND SPECIFICATIONS

CLEARFLOOR MODEL FEATURES

MODEL 30-20905A (See Fig. 1)

- Direct-driving design, minimize the lift wear parts and breakdown ratio.
- Dual hydraulic direct-drive cylinders, designed and made on ANSI standard, utilizing oil seal for cylinder.
- Self-lubricating UHMW Polyethylene sliders and bronze bush.
- Single-point safety release, and dual safety design.
- Clearfloor design, provide unobstructed floor space.
- Overhead safety shut-off device.
- Supersymmetric (2 in 1) arms design, makes it easier to find the lift point of the car.
- Stackable adapters 1.5", 3", 6" as standard.




Fig. 1

CLEARFLOOR MODEL SPECIFICATIONS

Model	Style	Lifting Capacity	Lifting Time	Lifting Height	Overall Height	Overall Width	Width Between Posts	Minimum Pad Height	Motor
30-20905A	Clear floor Direct-drive	4.5T 10,000Lbs	60S	1950-2080 mm 76-4/5" ~ 81-7/8"	3852 mm 151-2/3"	3516 mm 138-3/7"	2850 mm 112-1/5"	86 mm 3-2/5"	2.0/3.0 HP

Arm Swings View (For 30-20905A)




Fig. 2

II . INSTALLATION REQUIREMENT

A. TOOLS REQUIRED

- ✓ Rotary Hammer Drill ($\Phi 18$)
- ✓ Hammer
- ✓ Foot Level
- ✓ English Spanner (12")
- ✓ Ratchet spanner with socket (10#, 13#, 14#, 15#, 17#, 24#, 27#)
- ✓ Hex-key/Allen Wrench Set (5#)
- ✓ Carpenter's Chalk
- ✓ Screw Sets
- ✓ Tape Measure(7.5m)
- ✓ Needle Nose Pliers
- ✓ Lock Wrench

B. SPECIFICATIONS OF CONCRETE (See Fig. 3)

SPECIFICATIONS OF CONCRETE MUST BE ADHERED TO AS FOLLOWS. FAILURE TO DO SO MAY RESULT IN LIFT AND/OR VEHICLE FALLING.

1. Concrete must be thickness 150mm minimum and without reinforcing steel bars, and must be dried totally before the installation.
2. Concrete must be in good condition and must be of test strength 3,000psi (220kg/cm²) minimum.
3. Floors must be level and no cracks.




Fig. 3

C. POWER SUPPLY

The capacity of power must be 3HP minimum. The line must be 2.5mm² minimum and in good condition of contacting with floor.

III. STEPS OF INSTALLATION

A. Location of Installation

Check and insure the installation location (concrete, layout, space size etc.) is suitable for lift installation.

B. Use a carpenter's chalk line to establish installation layout of baseplate (See Fig. 4) .




Fig. 4

C. Check the Parts Before Assembly

1. Move aside the lift with forklift or hoist, and open the outer packing carefully , and check the parts according to the shipment parts list (see picture 1)



picture 1

2. Open the carton of parts and check the parts according to parts box list (see picture 2)

3. Check the parts of the parts bag according to parts bag list (see picture 3)



Picture 2



Picture 3

D. Position Powerside post

Lay down two posts on the installation site parallel, position the Powerside Post according to the actual installation environment. Usually, it is suggested to install Powerside Post on the front-right side from which vehicles are driven to the lift.

E. Assembly

Install Overhead Beam (30-20905A), Oil Hose Assy.

Note: The direction of Hydraulic Cylinder Fitting and the connection of the Oil Hose Assy.

should be in accordance with the sketch maps of Hydraulic System (**See Fig. 5**).

Otherwise, the Oil Hose would be damaged by the Lifting Head.

Model: 30-20905A




Fig. 5

F. Install Cable (see Fig. 6)

Model: 30-20905A




Fig. 6

G. Install Safety Device and Safety cable

(See Fig. 7)




Fig. 7

H. Fix the two Posts

Position posts, making sure their positions are conformed to the chalkline. Using the prescribed rotary hammer drill, drill all the anchor holes and install the anchor bolts. Make sure the posts level and plumbness with each other using the shims, and tighten the Anchor Bolts (See Fig. 8).





Fig. 8

I. Install Lifting Arms and Pads


Install the Lifting Arms, Lift Pads and and Snap Rings (See picture 4, 5); Attach the

Power Unit to the Powerside Post, connect the Oil hoses and tighten all the hydraulic fittings, and fill the tank with Hydraulic oil.

(Note: In consideration of Power Unit's durability and keep the equipment running in the perfect condition, please use Hydraulic Oil #46)



Picture 4



Picture 5

J. Install Electrical System (See Fig. 9)


Connect the power source as per the data plate of the Power Unit. **For 30-20905A:** make

sure the installation of the limit switch is correct (See Picture 6)

(Note: For the safety of operators, the power wiring must contact the floor well.


Pay attention to the direction of rotations when using 380V, three phase motors).

Model 30-20905A



380V, 3Phase

Fig. 9



Picture 6

Motor Wiring Diagram of Power Unit

For Clearfloor two post lifts 30-20904A and 30-20905A:

1. Connect two external power supply lines (Firewire L and the zero line N) to terminal blocks which are labeled L1, L2 on AC contactor respectively .
2. Connect two motor lines to terminal blocks which are labeled T1,T2 on AC contactors respectively.
3. Connect line A2 to L2 on AC contactor.
4. When connecting to the limit switch of Clearfloor two post lift, remove the terminal blocks 4 # on the control switch and A1 which marked on AC contactor first, and then connect two lines on limit switch to the terminal blocks 4# and A1. separately (See Fig.1 and Fig.2)





Fig. 3

**30-20905A-10
Motor Wiring Diagram of Power Unit**



**30-20905A-10
Circuit Diagram**




Fig. 4

Motor Wiring Diagram of Single Phase Power Unit (See Fig.6)


Clearfloor Model

1. Connect external power supply line (Firewire line L) to limit switch line 1#
2. Connect limit switch line #2 to motor line #5
3. Connect motor line #6 to control switch line #3
4. Connect control switch line #4 to external power supply line (Zero line N).

Floorplate Model

1. Connect external power supply line (Zero line L) to control switch line #4
2. Connect control line #3 to motor line #6
3. Connect motor line #5 to external power supply line (Firewire line L).

**Clearfloor Model –
Motor Wiring Diagram**



**Floorplate Model –
Motor Wiring Diagram**






Fig. 6

**30-20905A-10
Motor Wiring Diagram
of Power Unit
Fig. 8**




Valve Illustration of pump style 'A' and 'B' - SPX

Style "A"



Style "B" - SPX



IV. EXPLODED VIEW

Model 30-20905A




Fig. 10 (see page 22)

Cylinders




Fig. 11

Hydraulic Power Unit




Fig. 12

V. TEST RUN

1. Adjust Synchronous Cable (See Picture 7)

Use 14# Ratchet Spanner to hold the cable fitting, meanwhile use 24# Ratchet spanner to tighten the cable nut. Make sure two Cables are in the same tension so that two Lifting Heads can work synchronously. Fit the Plastic Hole Cover on the Lifting Head.

2. Adjust Safety Cable


Lift the carriage and lock at the same height, strain the safety cable and then release a little, and then tighten the cable screw. Make sure the safety device can always work properly.

3. Bleeding Air (See Picture 8)

This Hydraulic System is designed to bleed air by loosening the bleeding plug. Lifting the carriage to about 1 meter in height, and loosen the bleeding plug, the air will be exhausted automatically. Don't forget to tighten the plug after bleeding.



Picture 7



Picture 8

4. Adjust the lower speed

You can adjust the lower speed of the lift as required: loosen the Fixing Nut of the Throttle Valve, and then turn the Throttle Valve clockwise to decrease the lower speed, or counterclockwise to increase the lower speed. Do not forget to tighten the Fixing Nut after the lower speed adjustment has been done.

Note: For some power unit, the lower speed is fixed at factory and can't be adjustable.

5. Test with load

After finishing the above adjustment, test run the lift with a load. Run the lift in low position for several times first, make sure the lift can rise and lower synchronously, the Safety Device can lock and release synchronously. And then test run the lift to the top completely. If there is anything improper, repeat the above adjustment.




Fig. 13 Hydraulic System

VI. OPERATION INSTRUCTIONS

To lift vehicle

1. Keep the environment near the lift clean;
2. Position lift arms to the lowest position;
3. To shortest lift arms;
4. Open lift arms;
5. Position vehicle between columns;
6. Move arms to the vehicle's lifting point;

Note: The four lift arms must at the same time contact the vehicle's lifting point where manufacturers recommended

7. Press the **UP** button until the lift pads contact underside of vehicle totally. Recheck to make sure vehicle is secure;
8. Continue to raise the lift slowly to the desired working height, ensuring the balance of vehicle;
9. Push lowering handle to lower lift onto the nearest safety. The vehicle is ready to repair.

To lower vehicle

1. Be sure area is clear around and under the lift, only leaving operator in lift area;
2. Press the **UP** button to raise the vehicle slightly, and then release the safety device, lower vehicle by pushing lowering handle.
3. Open the arms and position them to the shortest length;
4. Drive away the vehicle.
5. Turn off the power.

VII. MAINTENANCE SCHEDULE

Monthly:

1. Re-torque the anchor bolts to 80-117 Nm;
2. Check all connectors, bolts and pins to insure proper mounting;
3. Lubricate cable with lubricant;
4. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage;
5. Check Safety device and make sure proper condition;
6. Lubricate all Rollers and Pins with 90wt. Gear oil or equivalent;

Note: All anchor bolts should take full torque. If any of the bolts does not function for any reason, DO NOT use the lift until the bolt has been replaced.

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, equalize tension of the cables to insure level lifting.
3. Check columns for plumbness.
4. Check Rubber Pads and replace as necessary.
5. Check Safety device and make sure in proper working condition.

VIII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	<ol style="list-style-type: none"> 1. Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. Height Limit Switch is damaged 5. AC Contactor burned out 	<ol style="list-style-type: none"> 1. Replace button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace the Limit Switch 5. Replace AC Contactor
Motor runs but the lift does not raise	<ol style="list-style-type: none"> 1. Motor runs in reverse rotation 2. Gear Pump out of operation 3. Release Valve is damaged 4. Relief Valve or Check Valve in damage 5. Low oil level 	<ol style="list-style-type: none"> 1. Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank
Lift does not stay up	<ol style="list-style-type: none"> 1. Release Valve not working 2. Relief Valve or Check Valve leakage 3. Cylinder or Fittings leak 	Repair or replace
Lift raises slowly	<ol style="list-style-type: none"> 1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with Air 4. Gear Pump leaks 5. Overloaded lift 	<ol style="list-style-type: none"> 1. Clean the oil line 2. Check electrical system 3. Fill tank 4. Replace Pump 5. Check load
Lift will not lower	<ol style="list-style-type: none"> 1. Safety devices are activated 2. Release Valve is damaged 3. Safety cable broken 4. Oil system is jammed 	<ol style="list-style-type: none"> 1. Release the safeties 2. Repair or replace 3. Replace 4. Clean the oil system

Clear floor Model 30-20905A (See Fig.10)				
Item	Part No.	Description	Qty.	Note
			30-20905A	
1	211001	Powerside Post	1	
2	209002	Power Unit	1	
3	209003	Hex Bolt	4	
4	209004	Rubber Ring	4	
5	209005	Nylok Nut	4	
6	209006	Safety Pin	2	
7	209007	Safety Spring	2	
8	209008	Safety Cover	2	
9	209009	Cup Head Bolt	4	
10	209010	Snap Ring	1	
11	209049	Plastic Pulley	3	
12	209012	Hair Pin	8	
Item	Part No.	Description	Qty.	Note
			30-20905A	
13	209013	Powerside Safety Assy.	1	
14	209014	Cylinder	2	
15	209015	Slider	16	
16	209016	Carriage Plastic Cover	2	
17	211002	Lifting Head	2	
18	209018	Protective Rubber	2	
19	209019	Bolt	12	
20	209020	Plastic Ball	4	
21	209021	Hex Nut	12	
22	209022	Washer	14	
23	209023	Teeth/Spring Washer	4	
24	209024	Arm Lock Bar	4	
25	209025	Hair Pin	4	
26	209026	Spring	4	
27	209027	Protective Rubber Sets	4	
28	209028	Lifting Arm – Rear Right (2-Stage)	1	
	213001	Lifting Arm – Rear Right (3-Stage)	0	
29	209029	Lifting Arm – Front Right (3-Stage)	1	
	213002	Lifting Arm – Front Right (2-Stage)	0	
30	209030	Lifting Arm Pin	4	
31	209031	Snap Ring	4	
32	209032	Socket Bolt	12	
33	209033	Washer	18	
34	209034	Lock Washer	12	

35	209035	Gear	4	
36	209036	Lifting Arm – Front Left (3-Stage)	1	
	213003	Lifting Arm – Front Left (2-Stage)	0	
37	209037	Lifting Arm – Rear Left (2-Stage)	1	
	213004	Lifting Arm – Rear Left (3-Stage)	0	
38	209038	Hex Bolt	6	
39	209039	Lock Washer	14	
40	209040	Lift Pad Weldment	4	
41	209041	Rubber Pad	4	
42	211004	Hex Bolt	1	
43	211005	Nylok Nut	1	
44	211006	Control Bar	1	
45	211007	Cup Head Bolt	2	
46	211008	Limit Switch	1	
47	211009	Hex Nut	2	
48	211010	Wire Cable	1	
49	211011	Top Beam W/Bracket	1	
Item	Part No.	Description	Qty.	Note
			30-20905A	
50	209046	Hex Bolt	4	
51	209057	Small Pulley	4	
52	209056	Nylok Nut	2	
53	211012	Offside Post	1	
54	211013	Offside Safety Assy.	1	
55	209051	Stackable Adapter (1.5")	4	
56	209052	Stackable Adapter (3")	4	
57	209053	Stackable Adapter (6")	4	
58	209054	Stackable Adapters Bracket	2	
59	209055	Hex Bolt	6	
60	209044	Pin For Pulley	2	
61	209045	Big Pulley	2	

For Floorplate & Clear floor Model 30-20905A

Oil Hose, Fitting & Cable (See Fig.5 , Fig.6 & Fig.7)				
Item.	Part No.	Description	Qty.	Note
			30-20905A	
62	209059	Anchor Bolts	12	
63	209060	90°Fitting for Hydraulic Power Unit	1	
64	209061	Oil Hose	0	

65	209062	T - Fitting	0	
66	209063	Oil Hose	0	
67	209064	Straight Fitting	0	
68	211014	Oil Hose	1	
69	211015	Oil Hose	2	
70	211016	T - Fitting	1	
71	211017	90 ⁰ Fitting (Extended)	2	
72	209065	Cable	0	
73	209066	Cable Nut	4	
74	211018	Cable	2	
75	209067	Cup Head Bolt	1	
76	209068	Safety Cable	0	
77	211019	Safety Cable	1	

Parts For Hydraulic Cylinder (See Fig. 11)

			30-20905A	
14-1	209069	O-Ring	2	
14-2	209070	Bleeding Plug	2	
14-3	209071	Support Ring	2	
14-4	209072	Y-Ring	2	
14-5	209073	O-Ring	2	
14-6	209074	Piston	2	
14-7	209075	O-Ring	4	
14-8	209076	Piston Rod	2	
14-9	209077	Piston Rod Fitting	2	
14-10	209078	Dust Seal	2	
14-11	209079	Head Cap	2	
14-12	209080	O-Ring	2	
14-13	209081	Bore Weldment	2	

Parts For Hydraulic Power Unit (See Fig. 12)

2-1	209082	Motor	1	
2-2	209083	Motor Connecting Shaft	1	
2-3	209084	Valve Body	1	
2-4	209085	Relief Valve	1	
2-5	209086	Lock Washer	4	
2-6	209087	Socket Bolt	4	
2-7	209088	Inlet Pipe	1	
2-8	209089	O-Ring	1	
2-9	209090	Filter	1	
2-10	209091	Hex Bolt	4	

2-11	209092	Tank	1	
2-12	209093	Bolt	2	
2-13	209094	Cover of Capacitor	1	
2-14	209095	Capacitor	1	
2-15	209096	Rubber Gasket	1	
2-16	209097	Hex Bolt	1	
2-17	209098	Cover of Motor Terminal Box	1	
2-18	209099	Push Button	1	
2-19	209100	Oil Outlet	1	
2-20	209101	Release Valve	1	
2-21	209102	Handle For Release Valve	1	
2-22	209103	Washer	1	
2-23	209104	Hex Nut	1	
2-24	209105	Check Valve	1	
2-25	209106	Gear Pump	1	
2-26	209107	Oil Return Pipe	1	
2-27	209108	Filler Cap	1	



THE CARTEK GROUP
6950 EAST N AVENUE
KALAMAZOO, MI 49048
PH: 269-382-5080
FAX: 269-382-5087
WWW.BEAR-CARTEK.COM
customerservice@cartek.com