





Montanari Group

GEARLESS & GEARBOX
TRACTION MACHINES



INSTALLATION, USE AND MAINTENANCE
GEARLESS

MGV25 RANGE



REV:3_03_2020

meyr Typenschild
meyr type tag



DOWNLOAD OUR APP!

A unique container of all documentation available for gearboxes, gearless, speed governors and safety gears.

You may check your supply, configure the inverter, download manuals, tech reports, certificates and much more.

Search for Montanari Giulio App, available on Google Play and App store.

SCAN THE QR TO DOWNLOAD ANDROID APP



SCAN THE QR TO DOWNLOAD iOS APP



Thank you for choosing a Montanari product.

Since 1970, Montanari Group has been focused on providing its customers with the best traction machines and components for lifts and escalators.

We are proud to have you as a customer and user of the Montanari traction machines, and we are confident that we can work together for a long time.








Thanks again for your choice.

Massimo Montanari
CEO of Montanari Group



REV.	DATE	DESCRIPTION	EDITED BY	VERIFIED BY	APPROVED BY
3	25/03/2020	First Redaction	Marketing Dept	Technical Dept Alberto Mantovani	STEFANO BERTONI (DTE)

WARNING SYMBOLS USED IN THE MANUAL:

	It indicates that safety measures must be taken to avoid electric shock.
	It indicates that safety measures must be taken to prevent personal injury.
	It indicates that safety measures must be taken to prevent damage to components.
	It indicates that safety measures must be taken to prevent burns due to contact with hot/ overheated surface.
	It indicates useful information before and during the installation step.
	It refers to specific parts of the manual.
	It refers to the proper product disposal.

CONTENTS

1.	GENERAL INFORMATION	7
1.1	Introduction.....	7
1.2	Copyright	7
2.	SAFETY.....	8
2.1	Intended use	8
2.2	User's obligations	8
2.3	Correct disposal	9
2.4	Specific hazards.....	9
2.5	Legal References	9
3.	IDENTIFICATION AND DATA	9
3.1	Identification plate	9
3.2	Dimensions.....	13
4.	TRANSPORT AND STORAGE	16
4.1	Handling.....	16
4.2	Storage.....	17
5.	DESCRIPTION	18
5.1	General description.....	18
5.2	Main components	18
5.3	Brake	19
6.	INSTALLATION.....	19
6.1	General installation information.....	19
6.2	Installation surface.....	20
6.3	Installation procedure.....	20
6.4	Electrical installation - Connections	22
7.	CONNECTION OF THE BRAKE FOR RESCUE SYSTEM.....	24
7.1	Connection of the cable to the brake levers.....	24
7.2	Connection of the cable to the hand release lever.....	26
7.3	Rescue System	26



8.	OPERATION	27
8.1	Connections	27
8.2	Additional components.....	27
8.3	General operation information.....	27
9.	TROUBLESHOOTING, MAINTENANCE AND REPAIR	27
9.1	General information	27
9.2	Traction/return sheave.....	28
9.3	Replacement of components	28
9.4	Problems, causes and solutions	28
9.5	Maintenance and repair	29
9.5.1	General indications	29
9.5.2	Description of maintenance activities.....	29
10.	SPARE PARTS	30
10.1	General information	30
10.2	How to order spare parts	30
11.	BRAKE CERTIFICATE	30
11.1	Exam certificate EU-BD 845 MGV25S-M.....	31
11.2	Exam certificate EU-BD 1014 MGV25ML-L	32
12.	COMPLIANCE DECLARATION	33

1. GENERAL INFORMATION

1.1 Introduction

These operating instructions must always be available for consultation. No liability is accepted for any malfunction due to installation not conforming to specifications, except in cases approved by Montanari Giulio & C.

All persons involved in the installation, operation, maintenance and repair of the unit must have read and understood the instructions.

No liability is accepted for damage, breakage or accident caused by failure to follow the instructions.

To make technical improvements, Montanari reserves the right, if deemed necessary, to modify the units and accessories, preserving their essential characteristics and improving efficiency and safety, without notice.

1.2 Copyright

All rights to these operating instructions belong to Montanari Giulio & C. S.r.l. The information in this manual may not be reproduced or used in an unauthorized manner or made available to third parties without prior approval.

If you have any questions, please contact:

MONTANARI GROUP
HEADQUARTER - MONTANARI GIULIO & C. Srl
Via Bulgaria 39 - 41122 - Modena - Italia
Tel: +39 059 453611 - Fax: +39 059 315890
www.montanarigiulio.com
info@montanarigiulio.com



2. SAFETY

2.1 Intended use

The MG25 gearless machine range is supplied ready for safe and reliable use. Any modification by the user that may affect safety or reliability is prohibited; it is also prohibited to tamper with devices or functions designed to prevent accidental contact.



The Montanari MG25 gearless machine range must be used and operated in strict compliance with the conditions set out in the supply contract.

Technical specifications considered: speed, cab capacity, cab weight, presence or absence of compensation, roping at the time of order.

No liability is accepted for any malfunction due to installation not conforming to specifications, except in cases approved by Montanari Giulio & C.

2.2 User's obligations

The operator must ensure that all persons involved in installation, operation, maintenance and repair have read and understood the supplied operating instructions and have adapted to them in order to:

- Avoid damage to property or persons.
- Ensure safe and reliable operation of the unit.
- Avoid breakage and environmental damage due to misuse.

In particular:

- Always observe the relevant environmental and safety regulations when transporting, assembling, installing, operating, maintaining and dismantling the unit.
- The unit must only be used, maintained and repaired by authorized, properly trained and qualified personnel.
- The gearless must not be cleaned using high-pressure cleaning equipment.
- All work must be carried out with care and with due attention to safety.
- Any work on the unit should only be carried out when it is not in operation.
- A warning must be placed on the main switch to clearly indicate that work is in progress on the unit.
- No welding must be carried out on the unit.
- Do not use the unit as a grounding point for welding operations.
- If any changes are detected (e.g. overheating or unusual noise) during operation, switch off immediately.
- Rotating components must be equipped with appropriate guards to prevent contact.
- If the unit is intended for installation in plant or machinery, the manufacturer of such plant or machinery must ensure that the standards, indications and descriptions contained in these operating instructions are incorporated into its own instructions.

- The information on the warning or identification plates must be complied with. These plates must be kept clean and legible at all times. Missing plates must be replaced.
- All spare parts can be obtained from Montanari Group.

2.3 Correct disposal



Respect the environment and dispose of the product according to the regulations in force in the country of installation.

2.4 Specific hazards

Depending on the conditions of use, the surface of the unit can become very hot.



Danger of burning!

2.5 Legal References

Tab. 1

N	Norm	Description
1	UNI 10147	Maintenance: Terminology.
2	EN 81-20	Safety rules for the construction and installation of lifts - Lifts for the transport of persons and goods.
3	EN 81 -50	Safety rules for the construction and installation of lifts - Examinations and tests.
4	EN 81 - 21	Safety rules for the construction and installation of lifts - Lifts for the transport of persons and goods - Part 21: New passenger and goods passenger lifts in existing building.

3. IDENTIFICATION AND DATA

3.1 Identification plate

The data on the plate are:

Fig. 1 - Example of Identification Plate

The identification plate contains the following information:

- Manufacturer:** Montanari Giulio & C.
- Manufacturer's address:** Via Bulgaria, 39, 41122 Modena - ITALY
- Year of production:** 2019
- Model:** MGX80
- Speed:** 96 - 53 RPM
- Rated torque:** 670 Nm
- Rated voltage:** 380 - 208 V_L
- Serial number:** 022611
- Frequency:** 25,6 - 14,1 Hz
- Rated current:** 15 A
- Cycle type:** S5 180S/H 40% ED
- Weight:** 330 Kg
- Power rating:** 6,7 - 3,7 kW
- Motor pole no.:** 32 Poles

Additional features include a QR code to access relevant documentation and a 'Download App' button.

GEARLESS MACHINE TECHNICAL CHARACTERISTICS: MG25S



Tab. 2

MG25S	Type	Pn	Speed	Vn	Cn	In	Cmax	Imax	EMF	Poles	F	Rs	Ls	Static Load	I	Duty Cycle	Weight
Code machine		kW	[RPM]	[V]	[Nm]	[A]	[Nm]	[A]	[V·s/rad]	[N°]	[Hz]	[Ω]	[mH]	[Kg]	[kg·m ²]		[Kg]
MG25100452B500	MGV25S	1,15	45	210	250	11	380	17	14	16	6	3,5	33	1800	0,2	180S/H 40%	120
MG25101152B500	MGV25S	2,8	115	210	235	13,5	320	19	10	16	15,3	2	18	1800	0,2	180S/H 40%	120
MG25100603B500	MGV25S	1,5	60	360	250	8,1	460	15	20	16	8	6,8	64	1800	0,2	180S/H 40%	120
MG25101203B500	MGV25S	3,1	120	360	250	11	460	21	14	16	16	3,5	33	1800	0,2	180S/H 40%	120
MG25101923B500	MGV25S	5	192	360	250	14,5	460	28	11	16	25,6	1,85	18	1800	0,2	180S/H 40%	120
MG25102803B500	MGV25S	7,6	292	360	250	19	460	36	8	16	37,3	1,2	11	1800	0,2	180S/H 40%	120
MG25103603B500	MGV25S	8,3	360	360	220	19,5	460	43	7	16	48	0,78	8	1800	0,2	180S/H 40%	120
MG25105103B500	MGV25S	11,7	510	360	220	26	460	56	3	16	68	0,46	4	1800	0,2	180S/H 40%	120

Tab. 3

BRAKE CHARACTERISTICS			
Model	Brake model	Power	Braking Force
		[W]	[Nm]
MGV25S	RTW250	2X79W	2X270Nm
		[V]	[A]
		207V _{dc}	0.4A
			Certificate
			EU-BD 845

GEARLESS MACHINE TECHNICAL CHARACTERISTICS: MG25M
Tab. 4

MG25M	Type	P _n kW	Speed [RPM]	V _n [V]	C _n [Nm]	I _n [A]	C _{max} [Nm]	I _{max} [A]	EMF [V·s/ rad]	Poles	F [Hz]	R _s [Ω]	L _s [mH]	Static Load [Kg]	I [kg·m ²]	Duty Cycle	Weight [Kg]
MG25150803B700	MG25M	3,2	80	360	385	12	665	21	20	16	10,7	3,8	40	3400	0,2	180S/H 40%	180
MG25151203B700	MG25M	4,8	120	360	385	15	665	27	15	16	16	2,25	25	3400	0,2	180S/H 40%	180
MG25151923B700	MG25M	7,7	192	360	385	20	665	36	12	16	25,6	1,4	15	3400	0,2	180S/H 40%	180
MG25152803B700	MG25M	11,3	280	360	385	27	665	50	9	16	37,3	0,75	8	3400	0,2	180S/H 40%	180
MG25153803B700	MG25M	15,3	380	360	385	35	665	62	7	16	50,7	0,47	5	3400	0,2	180S/H 40%	180

Tab. 5

BRAKE CHARACTERISTICS						
Model	Brake model	Power (P _n) [W]	Voltage (V _n) [V]	Current (I _n) [A]	Force (C _n) [Nm]	Certificate
MG25M	RTW350	2X 82 W	207V _{dc}	0,4 A	2X410 Nm	EU-BD 845

GEARLESS MACHINE TECHNICAL CHARACTERISTICS: MG25ML



Tab. 6

MG25ML	Type	Pn	Speed	Vn	Cn	In	Cmax	Imax	EMF	Poles	F	Rs	Ls	Static Load	I	Duty Cycle	Weight
Code machine		kW	[RPM]	[V]	[Nm]	[A]	[Nm]	[A]	[V·s/rad]	[N°]	[Hz]	[Ω]	[mH]	[Kg]	[kg·m ²]		[Kg]
MGV25200803BC00	MGV25ML	4,4	80	360	530	15	915	27	20	16	10,7	2,8	32	3400	0,28	180S/H 40%	220
MGV25201203BC00	MGV25ML	6,7	120	360	530	19	915	35	16	16	1,6	1,8	20	3400	0,28	180S/H 40%	220
MGV25201923BC00	MGV25ML	10,7	192	360	530	25	915	47	12	16	25,6	0,96	11	3400	0,28	180S/H 40%	220
MGV25202553BC00	MGV25ML	14,2	255	360	530	34	915	62	9	16	34	0,62	7	3400	0,28	180S/H 40%	220
MGV25203003BC00	MGV25ML	16,6	300	360	530	37	915	68	8	16	40	0,47	5	3400	0,28	180S/H 40%	220

GEARLESS MACHINE TECHNICAL CHARACTERISTICS: MG25 L

Tab. 7

MG25L	Type	Pn	Speed	Vn	Cn	In	Cmax	Imax	EMF	Poles	F	Rs	Ls	Static Load	I	Duty Cycle	Weight
Code machine		kW	[RPM]	[V]	[Nm]	[A]	[Nm]	[A]	[V·s/rad]	[N°]	[Hz]	[Ω]	[mH]	[Kg]	[kg·m ²]		[Kg]
MGV25260603BC00	MGV25L	4	60	360	630	15	1100	27	24	16	8	3,2	37	3400	0,31	180S/H 40%	240
MGV25261203BC00	MGV25L	7,9	120	360	630	22	1100	40	18	16	1,6	1,5	18	3400	0,31	180S/H 40%	240
MGV25261603BC00	MGV25L	10,6	160	360	630	28	1100	49	14	16	21,3	0,95	11	3400	0,31	180S/H 40%	240
MGV25262103BC00	MGV25L	13,9	210	360	630	32	1100	59	11	16	28	0,65	8	3400	0,31	180S/H 40%	240
MGV25262553BC00	MGV25L	16,8	255	360	630	40	1100	71	10	16	34	0,47	5	3400	0,31	180S/H 40%	240
MGV25263603BC00	MGV25L	23,7	360	360	630	52	1100	91	7	16	48	0,28	3	3400	0,31	180S/H 40%	240

Tab. 8

BRAKE CHARACTERISTICS						
Model	Brake model	Power (Pn)	Voltage (Vn)	Current (In)	Force (Cn)	Certificate
		[W]	[V]	[A]	[Nm]	
MGV25ML-L	RTW600	2X 372W – 2X 92W	207V _{DC-PEAK} - 104V _{DC-HOLD}	1.8A – 0.9A	2X600Nm	EU-BD 1014


3.2 Dimensions

The technical drawings and the overall dimensions follow.

Tab. 9

Gearless Type	Traction Sheave[mm]		Dimensions [mm]			
	Ø D	F	A	B	C	E*
MGV25S	160	88	500	300	344	55
	210	80		300	344	55
	240	80		342	357	52
	320	75				

Fig. 2
MGV25S






Tab. 10


MGV25M								
Pulley		Ropes			Dimensions			
ØD	F	Ø	min - max	Pitch	A	B	C	E
mm	mm	mm	n°	mm	mm	mm	mm	mm
210	106	6,5	3 - 8	12	568	301	344	55
			9 - 10	9,5				
240	70	6,5	3 - 8	12				
			9 - 10	9,5				
	106		3 - 8	12				
			9 - 10	9,5				
320	80	8	3 - 6	17		342	357	52
	115		7	13				
			8	12				

Fig. 3
MGV25M



Tab. 11

MGV25ML - L								
Pulley		Ropes			Dimensions			
ØD	F	Ø	min - max	Pitch	A	B	C	E
mm	mm	mm	n°	mm	mm	mm	mm	mm
210	106	6,5	3 - 8	12	689	315	362	64
			9 - 10	9,5				
240	70	6,5	3 - 8	12				
			9 - 10	9,5				
	106		3 - 8	12				64
			9 - 10	9,5				
320	115	8	3 - 4	17	342	67		
			7	13				
			8	12				

Fig. 4
MGV25ML - L




Only use lifting systems and equipment with adequate lifting capacity for handling. The entire packaging is designed to allow movement with for lift and for lift truck.

4. TRANSPORT AND STORAGE

4.1 Handling

All gearless machines are packed in crates or cages.

Different types of packaging can be used, depending on the size and means of transport. Unless otherwise specified, the packaging complies with the HPE guidelines.

In some cases, the machines are mounted on wooden pallets to enable them to be transported correctly on trucks. The packaging may not be stacked in any way. It is recommended to check the conditions of the material when it is received. In case of damage, do not proceed with the installation unless expressly authorized by Montanari Giulio & C. Observe the symbols on the packaging to prevent damage to property or personal injury. Here are the meanings of the symbols that may appear on the packaging.



Keep dry



Handle with care



Attachment point



Upper side



Do not use hooks



Keep away from heat sources



Fragile




Center of gravity



For lifting, anchor points (eyebolts) are provided as shown in Fig. 5.

Use only the specified eyebolts to handle the unit.



4.2 Storage

The gearless machine must be stored in the position of use on a wooden base not subject to vibrations, in a covered and sheltered place.



If the unit is stored outdoors, it should be covered, taking care that no moisture and/or other foreign matter can accumulate on it.



Supplies for special environmental conditions during transport (e.g. by ship) and storage (climate, temperature, etc.) must be contractually agreed.



- Check the correct operation of the motor and brake after installation.
- Repairs may only be carried out by the manufacturer or by authorised personnel.
- The machine can be red-hot.
- These machines must be connected to inverters.
- When the machine is rotating, both manually and mechanically, it can act as a generator and produce high voltage.
- During configuration, the machine is powered by high voltage.




5. DESCRIPTION

5.1 General description

The MGV25 series gearless machines are permanent magnet motors with double brake system.

5.2 Main components


The unit consists of the main groups as shown in Fig. 6.

MGV25 range is equipped with a PTC thermal probe inside the windings to protect against overheating (winding temperature up to 130°C) and with a thermo-contact for the activation of the fans. Refer to the electrical connections for more details. -  See Par. 6.4.

Lubrication



The gearless machine contains no oil and it is supplied with bearings already lubricated throughout the life of the machine; no further lubrication is required.



5.3 Brake

The gearless machine is supplied with a brake that conforms to the standards indicated in paragraph 2.5.

The brake system is pre-calibrated by the manufacturer and no further adjustment is required.



The brake system operates as follows:

- **Not powered** (electromagnet not powered): the brake disc is clamped by the movable surfaces (yellow arrows Fig. 7). In this condition the system does not move.
- When the brake electromagnet is **powered**, it releases the brake disc (yellow arrows Fig. 8); now the motor is released.




Fig. 7

Brake system not powered




Fig. 8

Brake system powered

6. INSTALLATION

6.1 General installation information



The gearless machine must be installed in a building or in a closed travel compartment.

Do not use the gearless machine in an explosive atmosphere.

The room temperature must be between 0°C and +40°C.

Assembly and installation must be carried out with great care by qualified and trained personnel.

The manufacturer cannot be held responsible for damage caused by incorrect assembly or incorrect installation.

Before starting work, make sure that adequate lifting and handling equipment is available.

No welding work must be carried out on the unit.

The unit must not be used as a grounding point for welding operations. The bearings can be irreparably damaged.

All fixing points specified by the manufacturer must be used.



The air supply for cooling must not be prevented.

6.2 Installation surface


The installation surface must be uniform and level.

The levelling tolerance is 0.1 mm.

The installation surface must be rigid and robust enough to withstand the forces involved.

6.3 Installation procedure

The gearless machine can be lifted using the eyebolts for the insertion of the belts or lifting chains (see also the paragraph on storage and handling). Particular attention is needed to avoid that the gearless machine receives blows in correspondence of the brake disc; the brake levers and the electrical connections of the board are very delicate. Lifting example Fig. 9.



Place the unit on the installation surface and secure it.


- Fixing screws and nuts must be tightened to the prescribed torque.
- Use bolts with a minimum strength class of 8.8.
- Do not force or hit the fixings to position them; this could damage the bearings, rings, etc.
- Mount the safety devices.

The static load changes depending on the roping direction. (Fig. 10):

Tab. 12

Bolt tightening torques (class 8.8)	
Thread	M20
Tightening torque (Nm)	410

Load direction






6.4 Electrical installation - Connections

The gearless machine is supplied with:

- Cable for the power supply of the motor [1 - 2 - 3, Ground, SC], for the power supply of the cooling fan (230 Vac) [F7-F8] and of the PTC guard [T5-T6] (Fig. 11).


Cable



- The power cable must be routed separately from the other cables.
- The motor power cable is shielded and the shield must be grounded.
- The encoder cable must be routed away from the motor power cable to avoid electrical interference.
 - The brake system has a power cable and another cable for the microswitch contacts. (Figure no. 12). All electrical data are listed on the label of the brake system. The microswitch has two contacts: one open and one closed. (Fig. 12).
 - These contacts indicate the brake condition (tab. 13).

Tab. 13

Brake disc closed		Condition contact	Brake disc free		Condition contact
BLACK	BLUE	Disconnected	BLACK	BLUE	Connected
COM. ——— / ———	N.O.		COM. ——— / ———	N.O.	
BLACK	GREY	Connected	BLACK	GREY	Disconnected
COM. ——— / ———	N.C.		COM. ——— / ———	N.C.	



Power supply
Brake

- **Standard mode:**

It is possible controlling only contactor 1 and leaving contactors 2 and 3 closed. (Fig. 13).

This protects the brake from dangerous overvoltage and noise when closing.


- **Emergency mode and inspection mode:**

The use of all contactors is recommended. Using only contactor no. 1 during opening and/or closing operations may cause an unacceptable delay when closing the brake.

Typical application with brake coils in parallel configuration.


MGV25 S - M

Fig. 13



MGV25 ML - L

Fig. 14





7. CONNECTION OF THE BRAKE FOR RESCUE SYSTEM

For installations with machine room, the cable and release lever are supplied as standard. The kit is shown in Fig. 15.




Fig. 15

Lever for manual
brake release.

Connection cable
for brake levers for
manual rescue system
(3.5 m).


Components for
fixing the cable.

7.1 Connection of the cable to the brake levers


Insert the end of the cable into the lever holes. Tension and fix. Fold the end and secure with the rope clamp as shown in the figure. At the end, the result is as in the figures below.

MGV25S


Fig. 16



MGV25M
Fig. 17




MGV25ML-L
Fig. 18






7.2 Connection of the cable to the hand release lever



Fix the lever to the wall with the bolts (not supplied). Connect the cable to the support as shown in Fig. 19.

Insert the other end of the cable into the screw hole. Tighten to stop. Fig. 20.

Fig. 20



7.3 Rescue System

It must be performed by an independent electrical device capable of opening the brake and moving the gearless machine at a reduced speed. The characteristics of the synchronous motor can be exploited as it slows down the cab when the phases are short-circuited.

8. OPERATION

8.1 Connections

Connect the motor, brake, and monitoring devices.

The connection must be made by qualified personnel in accordance with the applicable safety regulations. Installation and operation requirements and current national and international standards must be met.

8.2 Additional components

If third party additional components or options are installed, please refer to the information in the respective separate documentation provided.

8.3 General operation information

When operating the MGV25 unit, be sure to check that the following situations do not occur:

- Excessive operating temperature.
- Excessive and unusual noise.

If any irregularity occurs during operation, turn off the power immediately. Identify the cause of the malfunction by using the table in Chap. 9, containing a list of possible problems, causes and suggested remedies.



If the cause of the malfunction cannot be identified, or if the unit has been repaired using the means available, you should contact one of our service centres for a specialised service.

9. TROUBLESHOOTING, MAINTENANCE AND REPAIR

9.1 General information



Problems and malfunctions occurring during the warranty period, which are not precisely identified or which require work on the unit, must be referred to the manufacturer's Customer Service department.

Observe all safety rules.

Do not disassemble the motor on site.

The bearings are protected and do not require any additional lubrication under standard conditions of use.

Do not use high-pressure cleaners on the motor.

Montanari cannot guarantee or be held responsible for unauthorized operations on the unit, improper use, modifications made without its consent or the use of non-genuine spare parts.



When repairing problems or malfunctions, the unit must be put out of service in order to prevent unintentional start-up. Place a warning sign on the starting switch.



9.2 Traction/return sheave

Periodically, at least once a year, check the wear of the grooves in the traction sheave.

In case of slipping ropes or excessive wear, contact Montanari Giulio & C. for replacement instructions, always indicating the serial number.

9.3 Replacement of components

Instructions for the replacement of any component must be requested each time from the technical department specifying the serial number.

9.4 Problems, causes and solutions

Tab. 14

Diagnostic Table		
Problems	Causes	Solutions
The motor does not work	Motor phases are connected in the wrong way	Check the connection condition of the motor phases
	Wrong inverter configuration	Check the inverter settings
	Inverter defective	Replace the device
	Brake faulty	See below
	Motor mechanically locked	Contact Montanari Giulio & C.
	Motor connections loosened	Tighten the connections of the machine controller.
Brake system not working	Excessive temperature	See below
	Brake power supply wrong	Check the correct supply voltage of the brake coil.
Excessive temperature	Brake system defective	Contact Montanari Giulio & C.
	Cooling fan not working.	Replace the fan
	Cooling fan not correctly connected.	Check the voltage of the cooling fan. (230 V ac)
	PTC sensor defective	Contact Montanari Giulio & C.
Noise while travelling	Wrong inverter settings	Check the inverter settings
	Alignment of the motor with the deflection sheave incorrect.	Check and correct the alignment.
	Encoder defective	Replace encoder
	Wrong inverter settings	Check the inverter settings
	Bearing defective	Contact Montanari Giulio & C.

9.5 Maintenance and repair

9.5.1 General indications



The unit must only be used, maintained and repaired by authorized, properly trained and qualified personnel.

Compliance with the inspection and maintenance intervals is part of the conditions for the validity of the warranty.

9.5.2 Description of maintenance activities

Stop the unit and put it out of service. Place a warning sign on the start switch to prevent unintentional start.

Cleaning the unit.

Remove dirt on the unit with a hard brush.

Remove corrosion signs.

The unit must not be cleaned with high pressure washing equipment.



10. SPARE PARTS

10.1 General information



TIP

By keeping the main spare parts and wear parts in stock, the unit can always be used.

10.2 How to order spare parts

The manufacturer guarantees only genuine spare parts and accessories supplied by him.

Other parts not supplied by the manufacturer have not been tested or approved. The use of these parts can therefore compromise certain characteristics of the gearless machine and expose it to active and passive safety risks.



The manufacturer will not assume any responsibility and will not recognize warranty for damage caused by spare parts and accessories not supplied by the manufacturer himself.

When ordering spare parts, always specify:

- Order no. of the machine to which they must be applied;
- Description;
- Quantity.

To order spare parts, write to **service@montanarigiulio.com**.

11. BRAKE CERTIFICATE

The brake has been designed in accordance with the norm: EN 81 - 20:2014, EN 81-50:2015, EN81-1:1998+A3:2009(D).

This device can be used as a brake to slow down the cab in combination with a speed governor if the cab speed upwards is excessive.

The exam certificate is EU-BD 845 + EU-BD 1014.

11.1 Exam certificate EU-BD 845 MGV25S-M

ZERTIFIKAT ◆ CERTIFICATE ◆ 認証証書 ◆ CERTIFICADO ◆ CERTIFIKAT ◆ CERTIFICAT



Industrie Service

EU TYPE-EXAMINATION CERTIFICATE

According to Annex IV, Part A of 2014/33/EU Directive

Certificate No.: EU-BD 845

Certification Body of the Notified Body: TÜV SÜD Industrie Service GmbH
Westendstr. 199
80686 Munich - Germany
Identification No. 0036

Certificate Holder: Chr. Mayr GmbH & Co. KG
Eichenstr. 1
87665 Mauerstetten - Germany

Manufacturer of the Test Sample: Chr. Mayr GmbH & Co. KG
Eichenstr. 1
87665 Mauerstetten - Germany
(Manufacturer of Serial Production – see Enclosure)

Product: Braking device acting on the shaft of the traction sheave, as part of the protection device against overspeed for the car moving in upwards direction and braking element against unintended car movement

Type: RTW Size 150, 200, 250, 350
Type 8012.____.____

Directive: 2014/33/EU

Reference Standards: EN 81-20:2014
EN 81-50:2014
EN 81-1:1998+A3:2009

Test Report: EU-BD 845 of 2015-09-30

Outcome: The safety component conforms to the essential health and safety requirements of the mentioned Directive as long as the requirements of the annex of this certificate are kept.

Date of Issue: 2015-09-30

Date of Validity: from 2016-04-20

Achim Janocha
Certification Body "lifts and cranes"



TUV®



11.2 Exam certificate EU-BD 1014 MG25ML-L

ZERTIFIKAT ◆ CERTIFICATE ◆ 認証証書 ◆ CERTIFICADO ◆ CERTIFICAT



EU TYPE-EXAMINATION CERTIFICATE

According to Annex IV, Part A of 2014/33/EU Directive

Certificate No.: EU-BD 1014/1

Certification Body of the Notified Body: TÜV SÜD Industrie Service GmbH
Westendstr. 199
80688 Munich - Germany
Identification No. 0036

Certificate Holder: Chr. Mayr GmbH & Co. KG
Eichenstr. 1
87665 Mauerstetten - Germany

Manufacturer of the Test Sample: Chr. Mayr GmbH & Co. KG
Eichenstr. 1
87665 Mauerstetten - Germany
(Manufacturer of Serial Production – see Enclosure)

Product: Braking device acting on the shaft of the traction sheave, as part of the protection device against overspeed for the car moving in upwards direction and braking element against unintended car movement

Type: RTW Size 600, 800, 1000, 2000
Type 8012_ _ _ _ _


Directive: 2014/33/EU


Reference Standards: EN 81-20:2014
EN 81-50:2014
EN 81-1:1998+A3:2009

Test Report: EU-BD 1014/1 of 2016-09-09

Outcome: The safety component conforms to the essential health and safety requirements of the mentioned Directive as long as the requirements of the annex of this certificate are kept.

Date of Issue: 2016-09-26


Achim Janocha
Certification Body "lifts and cranes"



TUV®

12. COMPLIANCE DECLARATION



MONTANARI GIULIO & C. S.r.l.

COMPLIANCE DECLARATION
GEARLESS

Manufacturer:

Montanari Giulio & C. S.r.l.
Via Bulgaria n.39, 41122 Modena

Models concerned by the current declaration:

MGX19 – MGV19 – MSG19M – MGS19L – MGV20M – MGV20L – MG200.3 – MGX21 – MGV25S – MGV25M – MGV25ML – MGV25L – MGV34 – MGV34S – MGV34M – MGV34ML – MGV34L – MGV34.4 – MG34S.6 – MGV34.6 – MGX75 – MGX80 – MDD035 – MDD070 – MGV30.4 – MGV30.6 – MGX53 – MGX53S.

It is stated that the gearless in question comply with the Machines Directive 2006/42/CE as regards its relevant aspects and meets the following essential safety requirements as set out in Annex 1 of the directive:

- 1.3.2 risk of damage during the functioning;
- 1.5.1 electricity;
- 1.5.4 assembly errors;
- 1.5.8 noise;
- 1.5.9 vibration;
- 1.6 maintenance;
- 1.7.4 instructions.

The related technical documentation has been drafted in compliance with the Annex VII B.

Therefore, it complies with the following directives:

- 2014/33/UE, 2014/30/UE, 2014/35/UE

In addition, with the following regulations:

- UNI 10411-1; UNI 10411-3; UNI 10411-5; UNI EN 81-1:2010; UNI EN 81-20:2014

Note:

As regards, the fulfillment of the paragraph 9.7 of the UNI EN81-1:2010 and 5.5.7 UNI EN81-20:2014, it is recalled that Montanari provides safety device only upon explicit request by the customer.

Drafting:

Stefano Bertoni – Technical Director

Signature:

Massimo Montanari – Legal Representative

Massimo Montanari
Montanari Giulio & C. srl
Via Bulgaria, 39 - 41122 MODENA - Italy
Tel. +39 059 45 38 11
Cod. Fisc. e P. IVA 0104790366

Modena, il 20/03/2020

Montanari Giulio & C. Srl - Montanari Group Headquarter
Via Bulgaria, 39 - 41122 - Modena - Italia
Tel: +39 059 453611 - Fax: +39 059 315890 - info@montanarigiulio.com
www.montanarigiulio.com



Montanari Group
GEARLESS&GEARBOX
TRACTION MACHINES

MONTANARI GROUP HEADQUARTER
Montanari Giulio & C. Srl

Via Bulgaria 39 - 41122 - Modena - Italia

Tel: +39 059 453611 - Fax: +39 059 315890 - info@montanarigiulio.com

www.montanarigiulio.com

