

ACCU-PULSE

Installation Guide

1. Securely mount ACCU-PULSE by conveyor hydraulic unit return (on wall)
2. Remove existing conveyor hydraulic return line
3. Connect existing conveyor hydraulic return line to one port on ACCU-PULSE
4. Connect new hydraulic hose (supplied by customer) to other port on ACCU-PULSE
5. Connect new hydraulic hose to return to hydraulic unit
6. Wire ACCU-PULSE to Car Wash Controller

NOTE: This MUST be installed inline with conveyor motor return only



Mounting holes 3/8"

Mounting holes 3/8"

Motor Ports

