



# IN-LINE ALLEY AND SWEEP TUB

## STEP ONE

Attach the first bow to Palpation cage, Cattlemaster, Cattleman, or your existing chute using attachment rods. Note that the first bow has corral hardware on one side.



## STEP TWO

Attach two 10' straight alley panels to back of first bow.



## STEP THREE

Attach the second bow, making sure that adjustment handles remain on the same side.

This bow has drop-pin connectors on both sides.



## STEP FOUR

Attach first curved panel and one 10' straight alley panel to the second bow and lock with pins. Make sure that straight alley panel hooks to adjustable side of the bow.



## STEP FIVE

Attach main sweep bow, which contains sweep gate and the secondary bows, to 10' straight alley panel.



## STEP SIX

Spread out secondary bows. Attach first bow to first curved panel and lock with pins.



## STEP SEVEN

Attach second curved panel in the same manner.



## STEP EIGHT

Attach final curved panel as in steps 6 & 7.



## NOTE

Depending on the direction of the sweep, you may need to unbolt sweep gate latch assembly and mount to opposite side of sweep gate.



## ROUND 'EM UP! HEAD 'EM IN!

NOTE: When the Tarter Tub and Sweep System is set up in the straight-line configuration, the entry panel with arch and one 10' alleyway panel will not be needed. These parts may be used elsewhere in your cattle handling operation.



**TARTER**  
FARM AND RANCH EQUIPMENT

WWW.TARTERFARMANDRANCH.COM