



VOYAGER RACKS dot com

Made for: Land Rover

Model: Fits 2005-2016 Discovery 3 LR3 Discovery 4 LR4

Part No: VOYLR34VR (Low Pro, Standard, ORC, Campers)

Thank you for your recent purchase! The following is needed to install your new Voyager Rack.

- Box Knife to open packaging
 - Plastic Pry-Tool
 - Torx & Allen Keys
 - 10mm Wrench AND 10mm Ratchet
 - INCLUDED
- 8 LONG Spacers (use without rails, and on front of rack)
6 SHORT Spacers (use with rails, rear of rack only)
8- 6mm-Bolts
8- Fender/Flat Washers



Step 1: Lower vehicle to access mode

Step 2: Using Pry Tool, locate and remove all 8 plugs on roof of vehicle. Alternatively remove all six bolts attaching rails to your vehicle (TORX M6); LEAVE RAILS IN-PLACE), locate front mounting holes above driver and passenger doors.

Step 3: Remove any dirt, previous hardware, and place spacer over each threaded hole (short spacers if the vehicle has existing roof rails, long spacers if there are no rails). Using provided 6mm bolt, insert into threads and START all 8 bolts.

Step 4: Lift and set rack onto vehicle, allowing head of bolts to go through corresponding hardware on rack.

Step 5: Center Rack, and remove ONE bolt at a time, ADD WASHER to each bolt, REPLACE and START bolt.

Step 6: Center rack, tighten bolts until snug, and rack does not move when grabbed/vehicle shook.

SAFETY TIP: CHECK YOUR HARDWARE AFTER EACH VOYAGE

If you have any questions, or need assistance, please email

SALES@VOYAGEROFFROAD.COM or call/text:

+1 844-NAS-RACK

Thank you for your purchase!

-Voyager

