

Awning Drop Screen Installation Guide



1
Unpack Awning And Locate End Mounting Brackets



2
Locate Center Support Bracket(s)



Tilt Bar Nuts Into Valance Bar For Brackets



4
Install Idler End Bracket Leaving Bolt Loose



Install Drive End Bracket Leaving Bolt Loose



Center and Install Center Support Brackets (1/2" Wrench)

Awning Drop Screen Installation Guide



<p>Team Lift The Screen Into End Brackets / Install Pins</p>	<p>Loosen Bolts And Snap Roll Screen Into Center Supports</p>
<p>Ensure Support Bracket Hinge Bolts Are Tight</p>	<p>Adjust End Brackets and Tighten</p>
<p>Make Sure Retention Pins Are Installed In Both Ends</p>	<p>Test Screen Function</p>