





CUT & ALIGN THIS EDGE WITH BOTTOM SURFACE OF FRAME STOP (LEFT HAND)

WITH SCREWS PROVIDED PRE-DRILL (4) 1/8" HOLES

PARALLEL ARM APPLICATION MOUNT 180° TEMPLATE

SCREW IN VALVE ON BACK OF CLOSER

FROM CENTER LINE OF PIVOT LOCATE CLOSER & SHOE-CONTACT FACTORY IF USING SWING CLEAR HINGES
HINGE LINE / DOOR EDGE

CUT & ALIGN THIS EDGE WITH BOTTOM SURFACE OF FRAME STOP (RIGHT HAND)