

MILLENNIUM

CYCLE & MOTOR CYCLE

TOOLS

TELEPHONE ...

81 - BRAINTREE LAKE, BRAINTREE

Jake & Elliot, Itd.
BRAINTREE ESSEX

Works and Offices - - BRAINTREE
Branch Office-29 Hertford Street, COVENTRY

Jaks & Elliot, Itd.
BRAINTREE . ESSEX ...

PRIVATE-TO THE TRADE ONLY

The information given below is for the use of the Trade only. Traders are requested to remove this slip so that the Catalogue can be shown to their Customers.

RETAIL PRICES—All prices printed in plain figures in this Catalogue are RETAIL PRICES.

TRADE PRICES—These are concealed in the figures provided in italics following list numbers. To find the Trade Prices the last two figures should be read as pence and the preceding figures as shillings.

The following example is given:-

121/1206 Free Wheel Remover 17/-

This reads in code twelve shillings and sixpence and means that the TRADE PRICE is 12/6.

This code is used by the courtesy of Messrs. A. J. Dew & Co. Limited.



PAGE BOTTOM Bracket Tap	Page Bottom Bracket Tap 11 11 Bending Tools 15 15 Brazing Lamp 16 17 17 17 17 17 18 19 19 19 19 19 19 19
Bottom Bracket Tap	Bottom Bracket Tap
Bottom Bracket Tap 11 Bending Tools Brazing Lamp , , Spare Parts 17 Chuck, Drill 6 Crank Drawer 6 Crank Drawer 9 Cup Driver 9 10 9 10 11 Cycle Erector 3 10 10 10 11 12 12 12 13 14	Bottom Bracket Tap 11 Bending Tools 15 Brazing Lamp 16 """"""""""""""""""""""""""""""""""""
Bending Tools 15 Brazing Lamp 16 """"""""""""""""""""""""""""""""""""	Bending Tools 15 Brazing Lamp 16 """, Spare Parts 17 Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 """, Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 """, L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """, Quad 13 """, Adjustable 13 Pedal Pin Spanner 8
Brazing Lamp 16 """ Spare Parts 17 Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 """ Hub """ 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 """ 12 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """ Quad """ "" """ "" """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """	Brazing Lamp 16 """, Spare Parts 17 Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 """, Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 """, L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """, Quad 13 """, Adjustable 13 Pedal Pin Spanner 8
""" Spare Parts 17 Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 """ Hub """ Hub """ 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 """ """ Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ """ ""	""" Spare Parts 17 Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 """ 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 """>Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """>""" Quad 13 """ Adjustable 13 Pedal Pin Spanner 8
Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " " Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 " " "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Chuck, Drill 20 Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 , Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 , , L & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 , , , Quad 13 , , Adjustable 13 Pedal Pin Spanner 8
Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 , Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 , , L & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 , , , Quad 13 , , , Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 , , , , Wikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Cotter Extractor 8 Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " Adjustable 13 Pedal Pin Spanner 8
Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " " Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 " " " Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Crank Drawer 9 Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " " Adjustable 13 Pedal Pin Spanner 8
Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 "Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 ", L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ", Quad 13 ", Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ", ", "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Cup Driver 11 Cycle Erector 3 Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " " Adjustable 13 Pedal Pin Spanner 8
Cycle Erector 3 Die, Head Tube 10 ,, Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 ,, L & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, Quad 13 ,, Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, ,, "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Cycle Erector 3 Die, Head Tube 10 ,, Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 ,, L & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, Quad 13 ,, Adjustable 13 Pedal Pin Spanner 8
Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " " Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 " " " Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Walve Truer 14 Wheel Truers 4 Wringing Irons 15	Die, Head Tube 10 " Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 " " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 " " Quad 13 " " Adjustable 13 Pedal Pin Spanner 8
Jie Holder 10 Dies, Spoke 12 Drill, Breast, "Millennium" 18 ", " L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ", " Quad 13 ", " Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ", " " Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Walve Truer 14 Wheel Truers 4 Wringing Irons 15	""">"" Hub 10 Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 """>""">""">"" L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """>""">""">"" Quad 13 """>""">"" Adjustable 13 Pedal Pin Spanner 8
Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 ,, L & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, Quad 13 ,, Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, " "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Walve Truer 14 Wheel Truers 4 Wringing Irons 15	Die Holder 12 Dies, Spoke 12 Drill, Breast, "Millennium" 18 , , L & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 , , , Quad 13 , , , Adjustable 13 Pedal Pin Spanner 8
Dies, Spoke 12 Drill, Breast, "Millennium" 18 """ L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """ Quad 13 """ Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 """" Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Walve Truer 14 Wheel Truers 4 Wringing Irons 15	Dies, Spoke 12 Drill, Breast, "Millennium" 18 """ L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """ Quad 13 """ Adjustable 13 Pedal Pin Spanner 8
Drill, Breast, "Millennium" 18 ,, L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, Quad 13 ,, Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, ,, "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Walve Truer 14 Wheel Truers 4 Wringing Irons 15	Drill, Breast, "Millennium" 18 ,, L. & E. 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, Quad 13 ,, Adjustable 13 Pedal Pin Spanner 8
""" "" "" "" "" "" "" 19 Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 """ Quad 13 """ Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 """ "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	""" "" "" "" "" "" "" "" "" "" "" "" ""
Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, Quad 13 ,, Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, ,, "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Walve Truer 14 Wheel Truers 4 Wringing Irons 15	Fork Expander 9 Free Wheel Remover 7 Nipple Key 13 ,, ,, Quad 13 ,, ,, Adjustable 13 Pedal Pin Spanner 8
Free Wheel Remover 7 Nipple Key ,, Quad ,, Adjustable ,, Adjustable Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, ,, ,, "Mikado" 6 Tool Grinder Valve Spring Lifter Valve Truer Wheel Truers Wringing Irons	Free Wheel Remover 7 Nipple Key 13 ,, , Quad
Nipple Key 13 ,, , Quad 13 ,, , Adjustable 13 Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, , , , "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Nipple Key
""" "	""" """ """ """ """ """ """ """ """ ""
""" """ """ """ """ """ """ """ """ ""	,, ,, Adjustable 13 Pedal Pin Spanner 8
Pedal Pin Spanner 8 Screwing Machine, Spoke, "Millennium" 5 ,, ,, ,, "Mikado" 6 Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 4 Wheel Truers 4 Wringing Irons	Pedal Pin Spanner 8
Screwing Machine, Spoke, "Millennium" 5 """ """ <tr< td=""><td>Corowing Machine Cooks "Millannian"</td></tr<>	Corowing Machine Cooks "Millannian"
""" "	Screwing Machine, Spoke, Millennium 9
Tool Grinder 20 Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	,, ,, ,, "Mikado" 6
Valve Spring Lifter 14 Valve Truer 14 Wheel Truers 4 Wringing Irons 15	Tool Grinder 20
Valve Truer 4 Wringing Irons	Valve Spring Lifter 14
Wheel Truers 4 Wringing Irons 15	Valve Truer 14
Wringing Irons 15	Wheel Truers 4
	Wringing Irons 15.

TERMS OF BUSINESS

MAINTENANCE.

To prevent useless price cutting, goods are supplied to the trade on condition that they are not sold to the public below our published retail prices.

 $3_4^3\%$ Discount is allowed off all Prices in this catalogue for cash with order, or 21% for payment by the 20th of the month following date of invoices. No discount can be allowed after that date. Orders for goods at trade prices amounting in value to not less than £10 will be sent by Goods Train carriage paid.

With this exception goods are sent Carriage Forward.

To avoid delay, firms who wish us to open ledger accounts should send with their first order the usual trade references.

PRICE MAINTENANC

DISCOUNT AND CARRIAGE.

NEW CUSTOMERS.

PACKING AND CONSIGNMEN

CASES.


GUARANTEE. CONSIGNMENT.

All goods are well packed before leaving our warehouse. Purchasers are responsible after they have left our hands. If goods are not received within seven days of invoice date Purchasers should notify carriers.

Goods packed in cases are consigned at Carrier's risk. Customers are advised to sign for same as unexamined.'

Boxes and cases are charged at cost price, and if returned will be credited when received at our works in good condition, CARRIAGE PAID.

Our goods are not guaranteed for any specific period. If failures occur through faults either in material or workmanship, the goods should be securely packed, containing particulars of sender, and be sent to us Carriage Paid. All parts replaced will be sent Carriage Forward.



jaws.


nents are easy aised, lowered

nel. All parts

ort. The tray

at ... 60 lbs.

MILLENNIUM WHEEL TRUERS




These Stands take the narrowest cycle wheels and the widest motor cycle wheels.


Tables, carried by Steel bars, are fitted, shaped like trays, and will hold chalk for marking the rims, nipples, washers and nipple key; they form a rest for the hand and are adjustable for the various sizes of wheels.

They are also provided with a pointer, which can be set at any angle, and so indicate the parts of the rim requiring adjustment.


Illustration No. 1 shows Truer for Cycle Wheels only, and No. 2 one designed for both Cycle and Motor Cycle Wheels. Please state which model is required when ordering.

No. 102/2706 Price £1 16 6





PEDAL PIN SPANNER



This handy tool enables pedal pins to be removed without dismantling The ordinary type of spanner, even if thin enough on the jaws to go in the space provided, has not sufficient strength to withstand the strain.

In this tool the force applied to turn the pedal spindle tends to hold the jaws together, thus giving the necessary firm grip on the spindle. The jaw is made of the best quality steel.

> No. 115/506 Price

COTTER EXTRACTOR MILLENNIUM



The side arms fit cranks and hold tool in position.

Both hands can be used on the handle if necessary.

The screw is now fitted with a T handle, and is made long enough to clear the largest chain wheels.

The screw is fitted with a cap which cannot revolve with it and damage screwed end of pin.

Price

9/6

Weight 2 lbs.

MILLENNIUM CRANK DRAWER



Easily and quickly removes all tight cranks, either round or square, without removing the pedal.

The illustration readily shows how this tool is used.

Price ... 9/6 Weight ... 3½ lbs.

MILLENNIUM FORK EXPANDER



Easily and quie or square, with The illustration No. 130/700

Is of great service a front wheel, a taking out the makes it a real rubber to prevent the normal square in the service of th Is of great service for springing open the forks when removing a front wheel, and enables a back tyre to be changed without taking out the wheel.

It will not slip.

An improvement on other appliances for this purpose which makes it a really useful Tool. The Jaws are covered with rubber to prevent injury to the enamel.

Weight Price 5/3 6 ounces.

MILLENNIUM HEAD TUBE DIE-No. 2



Can be adjusted to cut & in. over or under the size it is marked. Size of die 2 in. outside diameter. It produces a full thread in one cut, provided the tube is not over the diameter required after screwing.

It is made in the following sizes:-

3½ in. by 30 threads (B.S.A.)—See note for this size.

1 in. by 24; 1 in. by 26.

No. 112/1500 Price complete ... 20/- Weight ... 13 lbs.

No. 112/506 Extra Dies ... 7/6

No. 112/900 Holder with Nuts, etc. ... 12/-

No. 112/010 Extra Guides ... 1/-

Note re 33 size:—We supply a cutter to go in this holder to reduce 1 in. tube to 34 in. which is necessary in order to cut a good thread, as otherwise there is too much metal for the die to remove.

No. 112a/506 Price ... 7/6

MILLENNIUM HUB DIE




This adjustable Die is made with B.S.A. thread for slightly reducing Hubs when too large for Free Wheel Clutches.

No. 113/1200 Price ... 16/- Weight ... 1\frac{1}{4} lbs

No. 113/1000 Price for Extra Dies, B.S.A. thread, 13/6 each

The Die is now made reversible so that the thread can be cut closer to the shoulder than before.



No. 117/1406	Price Complete Stand	ard Size	19/6
No. 117/906	Cutting Taps only	Price	12/6
No. 117/108	Guide Collars	,,	2/3
No. 117/406	Wrench, Spindle -2 Nuts		6/-







	CIRCULAR	R DIE HOLDE	:R
MILLENN	UM		
Fo	r holding Circ	ular Dies 1 in. dia	meter.
N	No. 109/209		3/9
WILLEN	NIIIM CI	RCULAR SP	OKE DIES
MILLER	Spec	cially suitable for	
MILLENNIU	Every	Die tested to th	
	These	Dies have a	reputation for
15G	unifor	mity of size, ea durability	
Sizes A	AND THREADS	of "MILLENNI	um" Dies.
FO MILLENNIA Gauge Gauge 6G	Threads per inch	Tested Outside Dia. of Threads cut by our Dies	Decimal Equivalents of Standard Wire Gauge
6G	32 32	.191 .192 .187 .188	.192 .1875
7G 8G	32 32 32	.175 .176 .159 .160	.176 .160
10G 11G	36 40 44	.143 .144 .127 .128 .115 .116	.144 .128 .116
12G 13G	44 56 u spr	.103 .104 .092	.104
14G 15G 16G	44 56 56 56 56 Threads	.091	.072
		Price	2/3
	No. 118/108	11100	

MILLENNIUM STEEL NIPPLE KEY



These Keys are made selected steel. from

LE KEY

The sare made country of the steel.

The cover flats.

The *No. 1 fits square nipples, 10 I.S.W.G. over flats. ,, ,, 9 ,, ,, No. 2 ,, No. 3 ,, 7 No. 123/1000 Price ... 13/6 per doz. *Fits 14, 15, and 16G. Nipples.

"QUAD" NIPPLE KEY



Those who prefer this style of Key will find it the best of its kind. It is guaranteed not to split.

1, 2, 3 are the same sizes as "Millennium" Keys, and 0 takes nipples 11G. over flats.

No. 124/200 Price ... 2/6

MILLENNIUM ADJUSTABLE NIPPLE KEY




Takes all Nipples in general use.

Very

Instantly adjustable.

No. 125/400 Price ... 5/6 each.

MILLENNIUM UNIVERSAL VALVE TRUER



This practical tool takes valves with stems from $\frac{1}{4}$ in. to $\frac{1}{2}$ in. diameter, or heads from 1 in. to 21 in. diameter.

The Cutter has four cutting edges. Two holes are provided for this Cutter, and for medium sized valves the blade can be used in either hole, giving eight cutting edges. The work is fed by a screw with a fine thread, which allows very light cuts to be taken.

The valves are rotated by a long carrier supplied with the tool.

No. 204/700 Price 9/6 No. 204/100 Extra Cutters 1/4

MILLENNIUM PARALLEL VALVE SPRING LIFTER



The parallel action removes the tendency to bend the Valve Stems. The lower Jaw is of a novel design, which enables it to be easily inserted between the ends of the valve and tappet.

Finished in a superior manner.

No. 205/506

Price 7/6

WRINGING IRONS No. C68





Machine cut jaws. Length over all Useful for straightening Cranks, etc.

No. C68/1100

Price (per pair) 14/6

MILLENNIUM BENDING TOOLS



For all bending and straightening operations. The design enables them to be used in awkward situations.

The Body is a Solid High Tensile Steel Forging. The studs are of specially selected steel.

Size 1 Length 17½ ins. No. 300/700 9/6 No. 300/1100 14/6 2 221 3 No. 300/1606 281 22/-

> No. 300/3406 Per set £2

Highest Quality. Low Price.



PRICES OF RENEWAL PARTS FOR BRAZING LAMP Burner Burner No.	PRICES OF RENEWAL PARTS FOR BRAZING LAMP	N L2/ L3/ L4/ L9a	P Io. 1506	FO	OF R BI	REN RAZIN	EW/ 1G	AL P.	ART P	ΓS		
Burner	Burner	N L2/ L3/ L4/ L9a	lo. 1506	FO	R BI	RAZIN	1G -	LAM	P			
Burner Solution Solution	Burner	L2/ L3/ L4/ L9a	lo. 1506									
Burner So. d.	No.	N L2/ L3/ L4/ L9a	lo. 1506	5		0						
No. L2/1506 Burner Complete 1 0 6 L3/703 Vapourizer Complete 0 9 9 L4/003 Nipple 0 0 4 L9a/106 Hood 0 1 4 L19a/100 Front Nozzle 0 1 4 L10/006 Back Nozzle 0 0 8 L13/004 Baffle Plate 0 0 5 L18/003 % in. Nuts and Bolts for Nozzle (!) 0 0 4 L19/001 % in. Screws for Hood 0 0 1½ L20/001 No. 3 B.A. Screws for Baffle Plate 0 0 5 L12/009 Spirit Tray 0 1 0 L24/003 Pricker for cleaning burner 0 0 4 L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	No.	L2/ L3/ L4/ L9a	lo. 1506	D		Kurn	er					
L2/1506 Burner Complete	L2/1506 Burner Complete	L2/ L3/ L4/ L9a	1506	D		Durii	CI			£	s.	d.
L3/703 Vapourizer Complete	L3/703 Vapourizer Complete 0 9 9 L4/003 Nipple 0 0 4 L9a/106 Hood 0 2 0 L9/100 Front Nozzle 0 1 4 L10/006 Back Nozzle 0 0 8 L13/004 Baffle Plate 0 0 5 L18/003 Å in. Nuts and Bolts for Nozzle (!) 0 4 L19/001 Å in. Screws for Hood 0 0 1½ L20/001 No. 3 B.A. Screws for Baffle Plate 0 0 1½ L16/004 Gauze Filter 0 0 5 L12/009 Spirit Tray 0 0 1 L24/003 Pricker for cleaning burner 0 0 4 Pump Pump Pump L5/709 Pump Rod Spring D 1 5 L5/18/003 Pump Rod Spring D 0 1½ L5/16/006 Pump Handle D 0 0 4 L5/16/006 Pump Rod (per Set) 0 0 4 L5/16/006 Pump Rod (per Set) 0 0 4	L3/ L4/ L9a	703	Burner	Compl	ete				1	0	6
L4/003 Nipple	L4/003 Nipple 0 0 4 L9a/106 Hood 0 2 0 L9/100 Front Nozzle 0 1 4 L10/006 Back Nozzle 0 0 8 L13/004 Baffle Plate 0 0 5 L18/003 År in. Nuts and Bolts for Nozzle (!) 0 0 4 1½ L19/001 År in. Screws for Hood 0 0 1½ L20/001 No. 3 B.A. Screws for Baffle Plate 0 0 1½ L16/004 Gauze Filter 0 0 5 L12/009 Spirit Tray 0 1 0 L24/003 Pricker for cleaning burner 0 0 4 L5/709 Pump Barrel Top 0 0 4 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L4/ L9a	103	Vapour	rizer Co	mplete				0	9	9
L9a/106 Hood 0 2 0	L9a/106 Hood 0 2 0 L9/100 Front Nozzle 0 1 4 L10/006 Back Nozzle 0 0 8 L13/004 Baffle Plate 0 0 5 L18/003 ½ in. Nuts and Bolts for Nozzle (!) 0 0 4 1½ L19/001 ½ in. Screws for Hood 0 0 1½ L20/001 No. 3 B.A. Screws for Baffle Plate 0 0 1½ L12/009 Spirit Tray 0 1 0 L24/003 Pricker for cleaning burner 0 0 4 L24/003 Pricker for cleaning burner 0 0 4 L5/18/003 Plump Barrel Top 0 0 4 L5/18/003 Plumper Leather 0 0 4 L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L9a	003	Nipple						0	0	4
L9/100 Front Nozzle 0 1 4 L10/006 Back Nozzle 0 0 8 L13/004 Baffle Plate 0 0 5 L18/003 % in. Nuts and Bolts for Nozzle (!) 0 0 4 L19/001 % in. Screws for Hood 0 0 1½ L20/001 No. 3 B.A. Screws for Baffle Plate 0 0 1½ L16/004 Gauze Filter 0 0 5 L12/009 Spirit Tray 0 1 0 L24/003 Pricker for cleaning burner 0 0 4 Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	L9/100 Front Nozzle		./106	Hood		•••				0	2	0
L10/006 Back Nozzle 0	L10/006 Back Nozzle 0 0 8	L9/	100	Front	Nozzle					0	1	4
L13/004 Baffle Plate 0 0 5	L13/004 Baffle Plate 0 0 5 L18/003 \frac{1}{16} in. Nuts and Bolts for Nozzle (!) 0 0 4 L19/001 \frac{1}{16} in. Screws for Hood 0 0 1\frac{1}{2} L20/001 No. 3 B.A. Screws for Baffle Plate 0 0 1\frac{1}{2} L16/004 Gauze Filter 0 0 5 L12/009 Spirit Tray 0 1 0 L24/003 Pricker for cleaning burner 0 0 4 Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1\frac{1}{2} L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L10	/006	Back N	Vozzle	•••	• • • • • • • • • • • • • • • • • • • •		•••	0	0	8
L18/003 % in. Nuts and Bolts for Nozzle (1)	L18/003 # in. Nuts and Bolts for Nozzle (1)	L13	/004	Baffle	Plate					0	0	5
L20/001 No. 3 B.A. Screws for Hood .	L19/001 & In. Screws for Hood	L18	/003	16 In.	Nuts ar	id Bolt	s for	Nozzle	(1)	0	0	4
L16/004 Gauze Filter	L20/001 Ro. 3 B.A. Screws for Ballie Flate 0 0 12	L19	/001	16 In. 3	Screws	for Ho	od " Pof	Ha Dlate	•••	U	0	11
L12/009 Spirit Tray	L12/009 Spirit Tray 0 1 0	L 16	/001	Gauge	Eilter	crews 10	n Dai	ne Flate	• • • • •	0	0	12
L24/003 Pricker for cleaning burner 0 0 4	L24/003 Pricker for cleaning burner 0 0 4	I 19	/009	Spirit	Tray			•••		0	1	0
Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L24	/003	Pricker	for cle	eaning	burne	r		0	0	4
Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0		1000	Titolici	101 11		same			ŭ	Ů	
Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 9 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	Pump L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0						-					
L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 9 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0					Pum	D					
L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 9 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	L5/709 Pump Complete 0 10 3 L6/101 Pump Barrel Top 0 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4											
L6/101 Pump Barrel Top 9 1 5 L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	L6/101 Pump Barrel Top	L5/	709	Pump	Comple	te				0	10	3
L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	L5/18/003 Plunger Leather 0 0 4 L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L6/	101	Pump	Barrel	Тор				0	1	5
L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8	L5/15/001 Pump Rod Spring 0 0 1½ L5/16/006 Pump Handle 0 0 8 003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L5/	18/003	Plunge	r Leath	er	•••			0	0	4
L5/16/006 Pump Handle 0 0 8	1003 Set of Washers, 2 Brass, 1 Leather for Pump Rod (per Set) 0 0 4	L5/	15/001	Pump	Rod Sp	oring				0	0	$1\frac{1}{2}$
009 Cat of Washers O.D. 1 T. 1 T.	Pump Rod (per Set) 0 0 4 L14/600 Pressure Gauge 0 8 0	L5/	16/006	Pump	Handle	. 0 D		 Leath		0	0	8
Pump Rod (per Set) 0 0 4	L14/600 Pressure Gauge 0 8 0	003		Set of	wasners Pump l	Rod (pe	er Set	Leather	ior	0	0	4
	L14/600 Pressure Gauge 0 8 0				-1	\P						
	L14/600 Pressure Gauge 0 8 0											
L14/600 Pressure Gauge 0 8 0		L14	/600	Pressur	re Gaug	ge				0	8	0
	L8/209 Filling Cap Complete 0 3 8	L8/	209	Filling	Cap Co	omplete				0	3	8
L8/209 Filling Cap Complete 0 3 8		L23	/001	Filling	Cap W	asher				0	0	2

L5/709	Pump Complete			 0	10	3
L6/101	Pump Barrel Top			 0	1	5
L5/18/003	Plunger Leather			 0	0	4
L5/15/001	Pump Rod Spring			 0	0	$1\frac{1}{2}$
L5/16/006	Pump Handle			 0	0	8
003	Set of Washers, 2 Br					
	Pump Rod (p	per Set)	 0	0	4

L14/600	Pressure Gauge	 	0	8	0
L8/209	Filling Cap Complete	 	0	3	8
L23/001	Filling Cap Washer		0	0	2



Jaks & Elliot, Itd.

L. & E. BREAST DRILL



ALL STEEL THROUGHOUT.

The Gears are Steel stampings with Machine Cut Teeth.

Handle is adjustable in four positions from $6\frac{1}{4}$ ins. to $3\frac{1}{4}$ ins.

Chuck takes drills up to $\frac{1}{2}$ in.

Two speeds. Instant Change.

The Rest is adjustable.


Fitted with improved steady handle.

Accurately Built for Accurate Work.

No. 302/1606

Price £1 2 0

MILLENNIUM TOOL GRINDER



The Driving Mechanism is substantial and readily gives the necessary high speed for satisfactory grinding, the whole being enclosed in a grease-retaining dust-proof cover.

The Grinding Wheel (size 6×14) is of best quality. An adjustable rest is provided.

A stand is provided for fixing to a bench when used for shop purposes. For use on the job the stem may be held in a vice.

INCLUDING GRINDING WHEEL

No. 219/2900 Price £1 18 6


GRINDING WHEEL

No. 219/803 Price 11/-

Treadle attachment for Tool Grinder

No. 220/906 Price 12/9

CHUCK



Chuck for use with small lathes, with ½ in. dia. shank.

No. 216/406

Price 6/-

