




Glueless Patch Kit




1. Find the hole in tube.



2. Use metal sander to roughen the damaged area.




3. Remove patch from backing then place patch over damaged area with the adhesive side facing the tube.




4. Press the patch firmly for 30 - 60 seconds to allow adhesive to firmly bond to the tube. Then reinstall tube into tire and inflate as normal.


Foot Pump Instructions




1. Release metal closure wire retaining the foot pedal by slightly depressing the foot pedal and rotating the closure wire.



2. Slide red switch to select desired valve type.





3. Slide pump head onto valve stem.
4. Lift thumb lever to lock head onto valve stem, then pump to inflate to desired pressure.
5. Lower thumb lever to unlock the pump head from valve stem then slide pump head off of valve stem.




6. To inflate, place foot on foot pedal and depress the foot pedal until it is fully compressed. Lighten the pressure on your foot and the pump will return to the start position. Once returned to fully extended position repeat the process until black pressure needle reaches your desired pressure.

17-Function Multi Tool



To separate tools:

1. Slide Tool 1 and Tool 2 apart by pulling ends.
2. To reassemble, simply align the grooves on back side of tools and slide together.



To close locking tools:

1. Depress and hold button.
2. Fold tool closed.

