

### **SAMi Cord Extension Instructions.**

1. Plug the end of the AC adapter cord into the end of the cord extension.
2. Wrap the end of the cord extension a couple times around the bracket to prevent the cord from pulling on the camera, then plug the end into the camera.
3. Use the included clips to route the cord along the wall, use one every couple feet. First clean the surface with isopropyl rubbing alcohol. Do not use household cleaners. Separate the adhesive strips and remove the blue liner from one. Press the adhesive strip to a clip. Remove the black liner from the adhesive and press the clip on to the wall. Repeat for each clip. The clip opening should be facing up when running the cord horizontally and to the side when running vertically. For best results alternate facing left and right when running up the wall. Press and hold the clip for 30 seconds. Maximum strength is reached after an hour.
4. To remove a clip, hold it gently while grasping the tab and pull **ALONG** the wall, stretching the adhesive until it releases.



**Do not chain more than two cord extensions. Strangulation Hazard - do not install within reach of a baby.**