






INSTRUCTIONS

SleeperHero.com


AGES 3+

WHAT YOU'LL NEED: 2 "AA" batteries // Small Phillips-head screwdriver

- 1 On the back of the doll, lift the fabric flap and using a screwdriver, loosen the screw until you can pivot the battery door open and insert 2 AA batteries in the orientation shown for + and - for batteries. Close the battery door and tighten screw.
- 2 Slide the OFF/ON/LOCK switch to "ON".
- 3 Press the button above SET MODE until a light is on for the CLOCK TIME. With hour flashing, press the up or down arrow to set hour time. Press ENTER. With minutes flashing, press the up or down arrow to set minutes time. Press ENTER.
- 4 For bedtime (labeled SLEEP) and with hour flashing, press the up or down arrow to set hour time. Press ENTER. With minutes flashing, press the up or down arrow to set minutes time. Press ENTER.
- 5 For WAKE TIME and with the hour flashing, press the up or down arrow to set hour time. Press ENTER. With minutes flashing, press the up or down arrow to set minutes time. Press ENTER.
- 6 Slide the switch to LOCK position on the side of the Battery Case. Note that when the switch is in the LOCK position, the CLOCK TIME, SLEEP TIME AND WAKE TIME cannot be changed until the switch is returned to the "ON" position. Also, note that after 30 seconds the clock display will go dark (stand-by mode for the clock).




- 7 Push the button on the chest and when the clock displays a time during SLEEP mode, the chest button will be RED. Push the chest button again to turn OFF. When the clock displays a time during AWAKE mode, the chest button will be Green. Push the chest button again to turn the light OFF. Note that the light will automatically turn OFF after 15 minutes without being pushed (to conserve battery life).



* NOTE:

When the doll is not being used, slide the switch on the side of the timer to the OFF position to save battery life. When the unit is turned OFF, the time will need to be re-set again.

Also, if you adjust the SLEEP and WAKE TIMES for naps, you may lose a few minutes over time and may need to adjust the CLOCK mode as needed.



PRECAUTION

- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Non-rechargeable batteries are not to be recharged.
- Batteries should only be changed under adult supervision.
- Do not dispose of batteries in fire, batteries may explode or leak.
- Remove old batteries.
- Do not use rechargeable batteries.
- Batteries are harmful if swallowed, so keep away from young children.
- Only batteries of the same or equivalent type as recommended are to be used.
- Remove battery if product is left unused for a long time.
- Please change the batteries when item does not work properly or batteries become weak.
- The supply terminals are not to be short-circuited.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate equipment.

Patent Pending.

This product conforms to current U.S. CPSIA and ASTM 963 Standards including toxic metal and phthalates requirements.



Cincinnati, OHIO

Made in China © 2014 Purple Pancakes, LLC

purple.pancakes.llc@gmail.com

purple-pancakes.com