

Golden Summer

Ambient Reverberator

This is the sound of a never-ending summer. Those nights when it was light out until 10 and your mom called you home from the back door. Skinned knees, fireflies in a jar and the smell of magnolia trees. Just let the nostalgia wash over you.

Controls:

Reverb Adjusts the size of the virtual reverb chamber.

Delay Controls the pre-delay or the delay time depending on mode.

Mix Controls the blend between fully dry (clean) and fully wet (reverb only) echo sound. 12 o'clock is an equal mix of clean and reverb.

Tweak Tweaks a different parameter in each mode. See the mode descriptions for full details.

Hint: The Tweak control has no effect when set to 12 o'clock. For a traditional reverb sound, start with the Mod mode and the Tweak control centered.

Mode Toggle:

Mod — Large chamber reverb with adjustable modulation. Turn the Tweak knob counter-clockwise for slow chorus, clockwise for fast vibrato.

Shimmer — A classic ambient effect that adds an octave to the reverb trails. Turn the Tweak control clockwise to add an octave up, or counter-clockwise to add an octave down.

Echo — A dedicated echo unit where the reverb is fed by the delay repeats for interesting rhythmic effects or longer echo washes. The Delay knob controls 400ms of delay time. Tweak knob adjusts the repeats and the delay tone - counter-clockwise for analog flavored dark repeats, clockwise for bright digital repeats.

Bypass Switching:

The Golden Summer features a buffered bypass with optional "trails." In Trails mode the delay will continue to repeat when the pedal is bypassed. To switch between standard bypass and trails, hold the bypass switch while powering on. The LED will blink once for standard bypass or five times for trails. The pedal remembers the last setting.



Power Supply:

The Golden Summer requires a 9V DC power supply with a 2.1mm pin, center negative. The Golden Summer is not designed to be powered on supplies higher than 9V and does not use a battery. The Golden Summer should work fine on a multi-pedal "daisy chain" connector, but if you encounter excessive noise or hum try a separate power supply.

ALEXANDER

GREAT TONES. DOING GOOD.

404 E. Main St, Garner, NC 27529 (919) 977-6665 alexanderpedals.com