

## GENERAL


Some of the Woolbubbles<sup>®</sup> standard groups are designed to be fitted in different patterns with fixed distance, approx. 6 cm between every panel. It is important that distance and grade of tilt is according to the scetch, in order to maintain harmony in the appearance of the group. Squarebubbles<sup>®</sup> and Town<sup>™</sup> groups can be placed without a fixed distance.

The back of the panel consists of a fabric with loops that firmly attaches to the hooks of the Velcro buttons included in the delivery. The Velcro buttons are to be fitted on the wall according to the scetches attached.

Standard screws and plugs are provided in the delivery, please make sure that they are suitable for the material of your wall.


## INSTALLATION

- Place the panels according to the pattern of the group on the floor. If appropriate, measure the distance between the panels to 60 mm. Please also note the total width and height of the group.
- On the wall, make marks of the width and height of the whole group, using a level to make it straight. Mark the position of each panel according to the group pattern. The easiest way to do this is to hold the panels, one at a time, against the wall and draw around it.
- Mark the positions of the Velcro buttons on the wall according to the scetches on the following pages. Pre-drill and screw the Velcro buttons to the wall. You can now wipe off all markings.











- Put the panels on the wall, without pressing too hard. Once they are all in position, take a step back and make sure they are in the right place. If necessary, make adjustments. When they have the correct position, press them hard and rub them firmly into place.














### EXAMPEL








## PLEASE CONTACT US PRIOR TO INSTALLATION:

- If you find a discrepancy or damage in your delivery.
- The wall is uneven and you need more Velcro buttons or a suggestion for alternative mounting.
- If the panels are placed in an area with a lot of movements, i.e. schools or pre schools, our recommendation is to use an extra firm assembly method.

	Name	Size/mm	Velcro buttons
	Angel	1000x810	7
	Carson	560x690	5
	Drop L	620x350	5
	Drop R	620x350	5
	Moon 11	Ø 300	3
	Earth 33	Ø 500	4
	Sirius	Ø 900	5
	Big Sun	Ø 1200	7

	Name	Size/mm	Velcro buttons
	Square XL	1200x1200	7
	Square L	600x600	5
	Square M	450x450	5
	Square S	300x300	4
	Square Circle L	600x600	4
	Square Circle M	450x450	4
	Square Circle S	300x300	4
	Square Stripe 1 L	600x600	4
	Square Stripe 1 M	450x450	4
	Square Stripe 1 S	300x300	4
	Square Stripe 2 L	600x600	4
	Square Stripe 2 M	450x450	4
	Square Stripe 2 S	300x300	4

	Name	Size/mm	Velcro buttons
	Barn	950x750	5
	House	450x530	5
	Townhouse	500x1350	6
	Apartment	700x1050	7
	Church	900x1650	8