



1 Power on the BOBO by pressing and holding the power button. While powering on, the Power LED will pulse green.
Power LED Green:
Default mode
>Toggle between modes by short presses on the power button.
Power LED Blue:
for snowboard games.



2 Make sure the Tablet Bluetooth is enabled. Pairing is automatic! Do not try to pair the BOBO with the tablet through the tablet's Settings tool. If you do, the BOBO will not be able to communicate with the tablet.
Wait 10-20 seconds and verify that the egg on the bottom right corner of the tablet wallpaper responds to the BOBO's movements. If the egg does not respond, wait another minute.



3 Choose game or training program.




BOBO app contains:


- 1. Training programs
- 2. Balance test
- 3. Custom made simple games



Freestyle Google Play games




4 Place the BOBO on an unstable balance training platform (Don't try to use it on the floor. The BOBO will not respond without tilt movements).
Example:




5 Position the BOBO directly in front of your TV / tablet, according to the game mode as shown below.

Power LED Green (default): Game mode facing the screen. The Power Button faces the screen (A).

Power LED Blue: Game mode perpendicular to the screen. The Power Button faces 90 degrees to the left of the screen (B).



A
facing the screen



B
facing 90 degrees to the left