


How to test the DC Control Board.

STEP 1:

Important: DO NOT run the D.C. Motor without the Wheel &/or Fan Blade.



LEAVE ALL CONTROL WIRES ATTACHED DURING TEST




National Comfort Products • 539 Dunksferry Road • Bensalem, PA 19020-5908
(800) 523-7138 • Phone (215) 244-1400 • Fax (215) 639-1674
www.nationalcomfortproducts.com

How to test the DC Control Board.

STEP 2:

Important: DO NOT run the D.C. Motor without the Wheel &/or Fan Blade.



How to test the DC Control Board.

STEP 3:

Important: DO NOT run the D.C. Motor without the Wheel &/or Fan Blade.

