



## LEVER LATCH

### STEP ONE

Unbolt Lever Latch from the gate and move it from it's shipping position (bars 3 & 4) on the gate to it's installation position (bars 2 & 3).

### STEP TWO

Attach Latch Assembly to the opening side of the gate. Secure tube anchorplates to the two rails of the gate.



### STEP THREE

Make sure Latch Assembly is flush against the opening end of the gate.



### STEP FOUR

Attach bolts to the upper and lower slots allotted for them. Make sure the bolts are secure and tight.



### STEP FIVE

Extend latch bolts to determine where to position latch receiver.



### STEP SIX

Drill 1/4" holes using the latch receiver as a template. Insert and secure bolts with crescent or socket wrench. Slide latch into receiver.



## STEP SEVEN

Attach latch bar and bolt securely to latch component\*.



## STEP EIGHT

Attach handle and bolt to secure\*.



## STEP NINE

Attach brace to handle to keep in place\*. *NOTE: Handle and brace bolts may need adjustment for proper operation.*



YOUR LEVER LATCH IS NOW COMPLETE AND READY TO USE.



**TARTER**  
FARM AND RANCH EQUIPMENT

\*Use bolts and nylon lock-nuts provided.