

# LoopCAD® 2016

Main new features for LoopCAD 2016:

- New **Main Menu** design with web-enabled features.
- New **Check for Updates** feature will automatically notify you when an update is available for download.
- Updated to **Manual J Eighth Edition Version 2.5** calculations (MJ8 Edition only).
- New **Mirror Drawing** function allows flipping of entire floorplan drawing along any axis.
- New **Move Floorplan** function.
- New **Multiple Tube Spacing** option now available in Quick Design Mode projects.
- Added options to show Floor Covering type, Room Volume and Perimeter on **Custom Tables** (Rooms table).

And here were some of the recent additions in 2015:

- New **Quick Design Mode** allows you to complete your design without drawing the detailed circuit layout. Reduces your design and quotation time by 50% or more, and lets you add the detailed circuits later if needed.
- New **Auto-Rotate** feature for building orientation. Finds the maximum cooling load orientation automatically.
- New **Thermostat** objects that can be added to your drawings (optional).
- New **Copy Table** feature allows you to copy tables to clipboard and paste them into other programs.

