



SUPERBOLT V2

Supro* tones in a pedal and a whole lot more! This discreet circuit does everything from clean boost to sagging exploding small amp distortion with ease.

*The word/name Supro is a registered trademark of Pigtronix. The JHS SuperBolt pedal is in no way affiliated with Supro® USA or Pigtronix.

CONTROLS

VOLUME - Controls the output volume.

DRIVE - Controls the amount of drive or gain just like a tube amp being cranked at high volumes.

STONE - Increases brightness. Right is brighter, left is darker.

GAIN TOGGLE - Engages higher gain mode when flipped up. The LED will turn red to indicate that you are in the higher gain mode.

JACKS

RED REMOTE JACK - The upper jack on the right side of the pedal is for a JHS "Red Remote" switch. Using this switch you can toggle between the higher gain mode and the standard mode on the fly.

INPUT - Lower jack on the right side of the pedal.

OUTPUT - Jack on the left side of the pedal.

POWER - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided. 3mA consumption.

JHS PEDALS