



# GERMANIUM BOOST

## OC71

Real germanium treble boost takes up the highs for a bright tone worthy of a stadium.

---

## CONTROLS

**KNOB** - Controls both output volume and gain saturation. Left is quieter with less saturation. Right is more loud with higher saturation.

**TOGGLE** - Adjusts EQ response. Down is the classic treble boost tone. Up adds bass frequencies.

## JACKS

**INPUT** - 1/4" on the right side of the pedal.

**OUTPUT** - 1/4" on the left side of the pedal.

**POWER** - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided.

**JHS PEDALS**