TECHNICAL RIDER

Updated and current as of October 20, 2017
*** RIDER IS SUBJECT TO CHANGE ***

- 1. **PURCHASER** shall not allow audience to enter place of performance until technical set-up has been completed. ARTIST shall complete said setup three hours prior to time of performance.
 - Artist requires a minimum one-hour sound check after completion of load-in and setup.

The place of performance must be made available to the artist three hours before theater is opened to the public. Festival producers are required to comply with this policy unless otherwise agreed in writing with the artist's representative.

- 2. **PURCHASER** shall provide a minimum of (3) stagehands to help ARTIST's crew load-in & out & stage set-up. A qualified electrician must be available at load-in until such time as ARTIST's stage manager releases him. In cases where ARTIST is staying overnight in the town of performance, **PURCHASER** will store ARTIST'S equipment overnight in a secured area and make it available to ARTIST the following day upon departure. If ARTIST is arriving and departing by air, **PURCHASER** will arrange for the equipment to be loaded and transported to and from the airport and the venue in a cargo van. When possible, this van will accompany the other vehicles transporting the ARTIST to airport.
- 3. **STAGE**: The stage should be a minimum of 40' wide x 30' deep with safety rails where required & appropriate ramps or stairs with handrails. Black skirting on front & sides (small events 32' wide x 24' deep)

 The stage must be accessible in a manner other than through the audience.
- 4. **BACKLINE**: PURCHASER shall provide the following equipment:

PIANO:

- (1) Optimally prepared and conditioned 7-9 ft. Piano (Steinway or Yamaha)
- Piano must be tuned to A440 pitch prior to sound check and thereafter as necessary.
- The quality and condition of the piano must meet ARTIST'S standards as verified by the ARTIST.
- PREFERRED Mics: Earthworks PM40 Piano Mics, or DPA 4099P, or Audix SCX 25

NOTE!.... IF ACOUSTIC PIANO IS NOT AVAILABLE PLEASE PROVIDE:

ELECTRIC KEYBOARD:

- 88 Weighted Keys (Yamaha Motif XF8/XS8 or Kurzweil PC3X)
- Piano Stand, sustain pedal, and adjustable drum stool

BASS AMP:

- (1) Eden WT1205 or WT550 or Galien Krueger 400RB or 800RB
- (1) Hartke or equivalent 1 x 15 or 4 x 10
- (2) High Quality speaker cables 15' (5 meters)
- (1) AC power drop 120V 50-60HZ

BARITONE SAXOPHONE (E-Flat)

"Any pro model baritone sax (low 'A' preferred but low 'B Flat' bari sax acceptable) from brands such as Selmer, Yanagisawa, Yamaha, P.Mauriat, Cannonball, Keilwerth, Buffet-Crampon, etc., (or equivalent) in good working order

PERCUSSION:

- (1) Set of Conga Drums LP Brand ... Latin Percussion with LP Cradle Stands
- (1) 11 ¾ Conga "Middle Drum"
- (1) 12 ½ Tumbadora "Low Drum"
- (1) Tuning Wrench
- (1) Set of extra matching Remo brand plastic heads (for Congas)
- (1) Please provide an extra set of new heads for all percussion
- (1) Set of LP Brand Timbales (Latin Percussion Tito Puente Model) with 14" & 15" Heads (Skins)

Contact Info: Oscar Hernandez @ 917-822-2224 vapiano1@mac.com

- (1) Heavy duty fully height adjustable tilting timbale stand & cowbell bracket.
- (1) Heavy duty cymbal stand and tuning wrench
- (Musician will bring his own cowbells and cymbal)

NOTE! *** Tito Puente Model only. Matador is a student model and not acceptable under any circumstance.

5. MISCELLANEOUS:

- (10) Professional Orchestra Music Stands...black metal shelf and height adjustable.
- (10) Clip on lights and sheet music clips (for Horns, Piano, Bass, & Percussion) with
- Electrical extension cords for all lamps & 120v AC power drops
- Three (3) Stools or chairs (piano, conga & bongo)
- Three (3) Radial JDI Direct boxes for Keyboard & Bass are preferred.
- One (1) Extra Straight Mic Stand at the Trombone 1 position (center horn for an iPad)

RISERS

- Note! When ever stage size allows Brass section should be on stage risers
- O Dimensions of 16' wide x 6' deep x 8" high or 20' wide X 8' deep x 8" high

FOR INTERNATIONAL DATES - PLEASE PROVIDE ADEQUATE VOLTAGE CONVERTERS

ANY SUBSTITUTIONS MUST BE APPROVED BY THE TOUR MANAGER OR AUDIO ENGINEER:

Backline equipment should be set up and on stage a minimum of two (2) hours before ARTIST'S sound check.

FRONT OF HOUSE SOUND SYSTEM

6. AMPLIFICATION & SPEAKER SYSTEM

- a. A high quality professional sound reinforcement system capable of providing clear undistorted sound of at least 125db, 20-16,000Khz with less than 1% total distortion at Front of House.
- b. Minimum 3-way tri-amped speaker system. (D-Vidosc, EAW, JBL, Martin, Meyer, D&B, SLS etc.)
- c. A high quality matching sub-woofer system, double 18" per enclosure preferred.
- d. Crossovers available at FOH Mix position.
- e. System should be configured in stereo with (2) Professional 1/3 Octave EQ's for the mains and an additional 1/3 Octave EQ for any clusters or balcony fills. (BSS, Klark, Ashly)
- f. Amplifiers: Camco, Crown, Lab Gruppen, Power Soft, QSC.

7. FOH MIXING CONSOLE

- a. Console location must be located at mid house and not in a booth or under balcony.
- b. Professional console with 32 input minimum, 8 Subgroups with inserts.
- c. 4 band fully parametric EQ (with Q) & 48 volt phantom power for each channel.
- d. A minimum of 8 aux sends for small events where console will serve as Front of House & Monitor console (6) auxes for monitors (2) auxes for effects.
- e. Console Preferences: Midas H1, H2, H3, XL3, XL4, Yamaha M7cl, PM 3500, 4000, 5000.

8. FOH PROCESSING for analog consoles

- a. (6) Channels insertable compression BSS, Aphex, or DBX 160 (No Behringer)
- b. (3) professional stereo digital reverbs. (Lexicon SPX 2000, PCM90, PCM 70 or 300)
- c. (1) Compact disc player
- d. (1) CD recorder.

MONITORS:

- 9. (1) 32-channel console with 4 band fully parametric (with Q), capable of (8) eight discreet monitor mixes. (Preferences: Yamaha M7cl, Midas H1, H2, H3, PM 3500, 4000, 5000)
- 10. (8) 1/3 Octave EQ's One for each monitor mix. (BSS, Klark Technics, Ashly)
- 11. (8) High quality bi-amped monitor wedges with 2" horn & 12" low speaker (Prefer EAW, JBL, Meyer, D&B, Martin)
- 12. (2) Professional digital reverb for monitors (Lexicon preferred).
- 13. (6) Channels insertable compression BSS, Aphex, or DBX 160 (No Behringer)
- 14. **ELECTRICAL** (1) 200 amp single or three phase for sound

15. **COMMUNICATIONS**

Contact Info: Oscar Hernandez @ 917-822-2224 vapiano1@mac.com

MICROPHONE & INPUT LIST

(Page 3 of 4)

SPANISH HARLEM ORCHESTRA

TIMBA BONG BONG BASS KEYB KEYB ACOL ACOL TRUM	GA ALES (Under) ALES (Overhead) GO (Under Chair) GO (Cowbell/Guiro) GOARD (LEFT) GOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	B57 / i5 B57 / i5 B57 / i5 SM81/SCX1 B57 / i5 S57 / i5 B57 / i5 ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	LP CLAW or Boom LP CLAW or Boom SHORT BOOM BOOM SHORT BOOM BOOM ¼" cable ¼" cable ¼" cable SEMI-CLOSED LID SEMI-CLOSED LID
TIMBA TIMBA BONG BONG BASS KEYB KEYB ACOL ACOL	ALES (Under) ALES (Overhead) GO (Under Chair) GO (Cowbell/Guiro) GOARD (LEFT) GOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	B57 / i5 SM81/SCX1 B57 / i5 B57 / i5 ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	SHORT BOOM BOOM SHORT BOOM BOOM ¼" cable ¼" cable ¼" cable SEMI-CLOSED LID SEMI-CLOSED LID
TIMBA BONG BONG BASS KEYB KEYB ACOL ACOL TRUM	ALES (Overhead) GO (Under Chair) GO (Cowbell/Guiro) GOARD (LEFT) GOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	SM81/SCX1 B57 / i5 B57 / i5 ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	BOOM SHORT BOOM BOOM 1/4" cable 1/4" cable 1/4" cable SEMI-CLOSED LID SEMI-CLOSED LID
TIMBA BONG BONG BASS KEYB KEYB ACOL ACOL TRUM	ALES (Overhead) GO (Under Chair) GO (Cowbell/Guiro) GOARD (LEFT) GOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	B57 / i5 B57 / i5 ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	SHORT BOOM BOOM ¼" cable ¼" cable ¼" cable SEMI-CLOSED LID SEMI-CLOSED LID
BONG BONG BASS KEYB KEYB ACOL ACOL TRUM	GO (Under Chair) GO (Cowbell/Guiro) GOARD (LEFT) GOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	B57 / i5 ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	BOOM ¼" cable ¼" cable ¼" cable SEMI-CLOSED LID SEMI-CLOSED LID
BONG BASS KEYB KEYB ACOL ACOL TRUM	GO (Cowbell/Guiro) GOARD (LEFT) GOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	1/4" cable 1/4" cable 1/4" cable 1/4" cable SEMI-CLOSED LID SEMI-CLOSED LID
BASS KEYB KEYB ACOL ACOL TRUM	SOARD (LEFT) SOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	ACTIVE D.I. D.I. D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	1/4" cable 1/4" cable 1/4" cable 1/4" cable SEMI-CLOSED LID SEMI-CLOSED LID
KEYB ACOL ACOL TRUM	JOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	1/4" cable SEMI-CLOSED LID SEMI-CLOSED LID
KEYB ACOL ACOL TRUM	JOARD (RIGHT) JSTIC PIANO Low JSTIC PIANO High	D.I. SM91 or better SM91 or better 421 / SM57 (no SM58)	1/4" cable SEMI-CLOSED LID SEMI-CLOSED LID
ACOL ACOL TRUM	JSTIC PIANO Low JSTIC PIANO High MPET 1	SM91 or better SM91 or better 421 / SM57 (no SM58)	SEMI-CLOSED LID SEMI-CLOSED LID
ACOL TRUM	JSTIC PIANO High	SM91 or better 421 / SM57 (no SM58)	SEMI-CLOSED LID
TRUM	NPET 1	421 / SM57 (no SM58)	
	ADET O	404 / CN457	
TROM	MPET 2	421 / SM57 (no SM58)	воом
	MBONE 1	421 / SM58	воом
TROM	/IBONE 2	421 / SM58	ВООМ
	TONE SAX	421 / SM57 or better	воом
FLUT		OM5 or better	ВООМ
_	N SOLO MIC STAGE LEFT	421 or better	воом
VOCA	AL 1	BLX24 WIRELESS (or equivalent)	STRAIGHT ROUND BASE
VOCA		BLX24 WIRELESS (or equivalent)	STRAIGHT ROUND BASE
VOCA	AL 3	BLX24 WIRELESS (or equivalent)	STRAIGHT ROUND BASE
VOCA	AL 4 (at Piano MC	BLX24 WIRELESS (or equivalent)	
talk)			ВООМ
Effect	Return 1 Left		
Effect	Return 1 Right		
Effect			
Effect Effect			
	talk) Effect Effect Effect Effect Effect Effect	talk) Effect Return 1 Left Effect Return 1 Right Effect Return 2 Left Effect Return 2 Right Effect Return 3 Left Effect Return 3 Right	talk) Effect Return 1 Left Effect Return 1 Right Effect Return 2 Left Effect Return 2 Right Effect Return 3 Left

Contact Info: Oscar Hernandez @ 917-822-2224 yapiano1@mac.com

MONITOR MIXES

1	LEAD VOCAL MIX		
2	PIANO/KEYBOARD		
3	PERCUSSION (ALL 3 ON ONE MIX)		
4	BASS		
5	TRUMPETS (2)		
6	TROMBONES (2) + SAX (OPTIONAL)		
7	HORN SOLO MIX		
8	CHORUS VOCAL MIX		

THE SPANISH HARLEM ORCHESTRA - STAGE PLOT



