



Sight line/Resultant Angle Square
Design - Pete Galbert, Steve First
Copyright (c) 2013

- Directions
- 1 Draw a base line through the mortise location to it's mate on the other side of the seat pattern.
 - 2 Position the scale along the base line so that the splay angle contacts the mortise location.
 - 3 Mark the rake angle along the other leg of the scale.
 - 4 Connect that mark with the mortise location to make the sight line.
 - 5 Measure the length of the sight line with the scale to get the drilling angle.
- Visit chairnotes.blogspot.com for video instructions,

