WESTERSTRAND Sweden

Westerstrand Time system

Maintenance Westerstrand slave clock

Document: 8457en01.doc Author: Joakim Jonsson Date: 4/5 2011 Page: 1 of 1

Maintenance of Westerstrand slave clock

Housing

A clean clock is always a more representative product. The exterior should regular be cleaned to maintain the clock in good condition.

Cleaning solutions

Never apply cleaning solutions directly to components. Solutions are always sprayed on the cloth, and then the cloth is used to wipe the component. Almost any type of household cleaner can be used to clean the outside of the clock case. The cleaner should not dissolve or scratch the finish. When rubbing alcohol is used with cotton swabs, the swabs should be moist, not dripping with solution. Avoid ammonia-based cleaners.

Movement

Movement is built to have a long working cycle and is intended to be maintenance free. The movement is lubricated with high-grade lithium-soap grease on a synthetic oil basis which is proved to be very resistant to ageing.