


Technical Details:

- Dimensions(chipset): 132x 103 x 14mm
- Dimensions(vreg): 106x 18x 18mm
- Ports: G1/4"

Box Contents:

- 1x X79 Chipset Waterblock
- 1x Thermal Paste
- 1x X79 Vreg Waterblock
- 2x Thermal Pads


The installation process below is shown without the tubing connected. This has been done so the installation process can be seen clearly. All watercooling components should be connected and leak tested prior to installation into a PC.




1. Remove the highlighted screws on the back of the motherboard and carefully remove the stock heatsinks.



2. Clean the old thermal paste from the chipset. Apply fresh thermal paste to the chipset and place the two thermal pads on the position marked at the top of the board.



3. Remove the plastic film from the blocks and carefully place the blocks in the positions shown below.



4. Attach the waterblocks using the provided screws. You should be careful to tighten the screws gradually. Over tightening or unevenly tightening the screws could damage the motherboard.

When you first start the PC after installing the blocks it's advisable to monitor the temperatures in the bios or use some temperature monitoring software. If the temperatures appear higher than expected you may need to reset the blocks.