












<p>Step 1:</p>  <p>Attach the sterile filter needle onto each 60mL syringe. Then draw 6mL of Sodium Citrate Anticoagulant into each 60mL Syringe</p>	<p>Step 2:</p>  <p>Draw 108mL of bone marrow aspirate from the patient, fill each syringe to 60mL</p>	<p>Step 3:</p>  <p>Start End Filter For each BMA syringe, filter the BMA in the direction indicated on the filter.</p>	<p>Step 4:</p>  <p>Inject 60mL of anticoagulated & filtered BMA into each Concentrating Device</p>	<p>Step 5:</p> <p>Counterbalance the devices</p> <p>Then process the Concentrating Devices at:</p> <p>Executive Series Centrifuge 2.5 minutes 3800 RPM</p> <p>Platinum Series Centrifuge Pre-Programmed Setting: "PureBMC® SP Spin 1"</p>
<p>Step 6:</p>  <p>Aspirate the BMA plasma into each 60mL syringe. Then open the stopcock to the 3mL syringe and aspirate 2mL of BMA red blood cells into each 3mL syringe</p>	<p>Step 7:</p>  <p>For each syringe set Inject BMA Plasma Second</p> <p>For each syringe set Inject 2mL RBC FIRST</p> <p>Transfer the BMA RBC and Plasma from both syringe sets into the Concentrating Accessory. For each syringe set inject BMA RBC first.</p>	<p>Step 8:</p> <p>Counterbalance the devices</p> <p>Then process the Concentrating Accessory at:</p> <p>Executive Series Centrifuge 7 minutes 3800 RPM</p> <p>Platinum Series Centrifuge Pre-Programmed Setting: "PureBMC® SP Spin 2"</p>	<p>Step 9:</p>  <p>BMA Buffycoat</p> <p>Bone marrow cell concentrate buffycoat separates out at the bottom of the Concentrating Accessory</p>	
<p>Step 10:</p>  <p>Aspirate BMA Plasma Leave approximately 14mL</p> <p>Aspirate BMA plasma from the Concentrating Accessory. Leave 14mL of plasma.</p>	<p>Step 11:</p>  <p>Attach the 20mL syringe and swirl to resuspend the BMA buffycoat into the plasma.</p>	<p>Step 12:</p>  <p>Tilt to immerse Aspirating Pipe into PureBMC®</p> <p>Tilt to immerse the Aspirating Pipe into the PureBMC®</p>	<p>Step 13:</p>  <p>14mL PureBMC®</p> <p>Extract the PureBMC® into the 20mL syringe.</p>	