














<p>Step 1:</p>  <p>1 2 3 4 5 6</p> <p>Draw 1.5mL of Citrate Anticoagulant onto the 12mL syringe</p>	<p>Step 2:</p>  <p>1 2 3 4 5 6</p> <p>Draw 8.5mL of bone marrow aspirate from the patient, filling the syringe to 10mL</p>	<p>Step 3:</p>  <p>Start End</p> <p>Filter</p> <p>Filter from 12mL syringe to 60mL syringe by simultaneously pushing and pulling each syringe. Filter the BMA in the direction indicated on the filter.</p>	<p>Step 4:</p>  <p>Inject anticoagulated & filtered BMA into the Concentrating Device</p> <p>Step 5:</p>  <p>Counterbalance and process the Concentrating Device at 2.5 minutes 3800 RPM</p>
<p>Step 5:</p>  <p>BMA Plasma 2mL BMA RBC</p> <p>Aspirate the plasma into the 60mL syringe. Then open the stopcock to the 3mL syringe and aspirate 2mL of red blood cells</p>	<p>Step 6:</p>  <p>Inject BMA Plasma Second Inject 2mL RBC FIRST</p> <p>Transfer the RBC first then the plasma into the Concentrating Accessory</p>	<p>Step 7:</p>  <p>time press start/stop 7.0 3.8 speed press rpm/rvd short open</p> <p>Counterbalance and process the Concentrating Device at 7 minutes 3800 RPM</p>	<p>Step 8:</p>  <p>Platelet Buffycoat</p> <p>Platelet concentrate buffycoat separates out at the bottom of the Concentrating Accessory</p>
<p>Step 9:</p>  <p>Aspirate Plasma Leave approximately 7mL</p> <p>Aspirate plasma from the Concentrating Accessory. Leave 7mL of plasma.</p>	<p>Step 10:</p>  <p>Attach the 12mL syringe and swirl to resuspend the platelet buffycoat into the plasma.</p>	<p>Step 11:</p>  <p>Tilt to immerse Aspirating Pipe into PureBMC® PRP</p> <p>Tilt to immerse the Aspirating Pipe into the PureBMC® PRP</p>	<p>Step 12:</p>  <p>7mL PureBMC® PRP</p> <p>Extract the PureBMC® PRP into the 12mL syringe.</p>