

Kabebari batten detail

Profile: Plank 100x12mm

Base: 0.692kg/m

Cover: 0.417kg/m


Total: 1.109kg/m

Batten thickness: 1.0mm


End cap thickness: 2.0mm

Standard lengths: 4000, 6100mm.


Note: Longest full piece is 5700mm.







Endcap detail



Installation detail



Not to scale

	Install	Ensure there is a 1mm gap between the base male sections when installing. Insufficient spacing will result in difficulty attaching female sections.	Product Name				Project Name	Creation Date	Page	Scale	Projection
		Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.	Ever Art Wood - Kabebari				Plank 100x12		1 of 3	1:1
	End caps	Apply exterior grade adhesive (Sikaflex) to secure cap to batten.	Approval	Chek	Drawing	Design	Customer	Distributor		Manufacturer	
	No.	DATE						covet			

Kabebari batten detail

Profile: Nami Plank 100x12mm


Base: 0.692kg/m

Cover: 0.458kg/m


Total: 1.15kg/m

Batten thickness: 1.2mm


End cap thickness: 2.0mm







Endcap detail



Installation detail







Not to scale

	Install	Ensure there is a 1mm gap between the base male sections when installing. Insufficient spacing will result in difficulty attaching female sections.	Product Name				Project Name	Creation Date	Page	Scale	Projection
		Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.	Ever Art Wood - Kabebari				Nami Plank 100x12		2 of 3	1:1
	End caps	Apply exterior grade adhesive (Sikaflex) to secure cap to batten.	Approval	Chek	Drawing	Design	Customer	Distributor		Manufacturer	
No.	DATE							covet			

Kabebari Batten Installation Guide

- Aluminium can be damaged if mishandled. Never strike directly with a hammer or rubber mallet. Use a pine plank between the striking rubber mallet and the extrusion to avoid surface damage or denting.
- Cut aluminium with a drop saw using an aluminium blade.
- Always cap ends of extrusions with supplied end caps or a flashing to avoid moisture ingress.
- Plastic end caps must be securely inserted with screws supplied or sikafelx applied to the inside of the extrusion before inserting. This will prevent slippage of the extrusion.
- All end caps can only be applied to straight 90 degree cuts. They cannot be applied to angle end cuts.
- Ensure appropriate screws are used to suit the substrate you are fastening to. It is important to use stainless steel or bi-metal screws for all metal surfaces impacted when fastening (i.e. furring channels, top hats, steel frames). This will prevent galvanic reaction between the screw/substrate and aluminium extrusion.
- Fasten at maximum 1 metre spans. Please contact Covet for further information.
- Always fasten the male (base) section first. The female (top section) clips over the top. They can also slide on if necessary.
- When butting together 12x100 planks ensure there is a 1mm gap between the base male sections. Failure to allow sufficient spacing will result in difficulty attaching female sections.

	Install	Ensure there is a 1mm gap between the base male sections when installing. Insufficient spacing will result in difficulty attaching female sections.	Product Name				Project Name	Creation Date	Page	Scale	Projection
	Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.	Ever Art Wood - Kabebari				Plank & Nami Plank 100x12		3 of 3	1:1	
	End caps	Apply exterior grade adhesive (Sikaflex) to secure cap to batten.	Approval	Chek	Drawing	Design	Customer	Distributor		Manufacturer	
No.	DATE							covet		